

AQ115A,AQ115B,AQ130A,AQ130B,AQ130C,AQ130D,BB115A,BB115B,BB115C



5248

AQ115A,AQ115B,AQ130A,AQ130B,AQ130C,AQ130D,BB115A,BB115B,BB115C

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	462653	1	Cylinder block		
2		5	· BEARING CAP		
3	942852	10	· Screw		1/2"UNC
	945799	10	· Screw		M12
4	430119	1	· Bushing		
5	418249	1	· Bushing		
6	418250	1	· Bushing		
7	418251	1	· Bushing		
8	192212	6	· Plug		
9	950562	2	· Pin		
10	952076	1	· Plug		
	952075	2	Plug		
11	418416	1	Oil jet		
12	19730	2	Locating pin		
13	82745	1	Tap		EARLY TYPE
	831496	1	Tap		LATE TYPE
14	419743	1	Oil trap		D = 22 MM, EARLY TYPE. EXCL. SPEC. 9882, 9961, 9982.
	419808	1	Oil trap		D = 27 MM, LATE TYPE. EXCL. SPEC. 9882, 9961, 9982.
15	418412	1	Sealing ring	IK	I.D = 22 MM, EARLY TYPE
	419805	1	Sealing ring	IK	I.D = 27 MM, LATE TYPE
16	950045	1	Screw		
17	942390	X	Hose		L = 330 MM
	942390	X	Hose		L = 250 MM. SPEC. 9881, 9890. 9919, 9958, 9960.
18	824544	1	Oil trap		D = 22 MM, EARLY TYPE. SPEC. 9882, 9961.
	824691	1	Oil trap		D = 27 MM, LATE TYPE. SPEC. 9882, 9961.
19	819866	1	Clamp		SPEC. 9882, 9961.
20	950046	2	Screw		SPEC. 9882, 9961.
21	950352	1	Lock nut		SPEC. 9882, 9961.
22	824754	1	Tube		SEE GROUP 3
23	955359	1	Screw		SEE GROUP 3
24		1	LIFT EYE		
25	942336	1	Spring washer		
	941908	1	Spring washer		
26	940114	1	Screw		L = 22 MM
	955315	1	Screw		L = 20 MM
27	418645	1	Tube, PIPE	02A-1200	
				02A-1225	
28	463902	1	Expansion plug	02A-0600	
29	824626	1	Nozzle		EXCL. SPEC. 9882, 9961, 9982, 9983, 867041, 867157, 817171.