



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	HEAT EXCHANGER WITH INSTALLATION COMPONENTS	02B-0650	
2	828026	1	Sea water pump	02B-1150	
	855578	1	Sea water pump		
3	831622	2	Gasket	IK	
4	831903	1	Flange		
5	956094	2	Screw		
6	831906	1	Tube		
7	834722	1	Tube		AQ140A, FOR LATE TYPE OF STEERING SYSTEM.
8	418412	1	Sealing ring	IK 02B-0650	
9	831622	1	Gasket	IK	
11	955271	2	Screw		
14		1	SCREW UNION		SEE GROUP 2A
19	831622	1	Gasket	IK	
20	834979	1	Pipe		AQ125A USA SPEC 867650 MO-76501100. AQ125A USA SPEC 867679 MO-76796526-. AQ125A SPEC 867680 MO-7680953.. REPLACED BY 841913 + 841906 + 955138 + 960138 + 952632. AQ125A USA SPEC 867650 MO76501101-, AQ125A USA SPEC 867679 MO76796527-, AQ125A SPEC 867680 MO 7680954-.
20A	180759	1	Plug		MOXXXX/155078-
21	955271	2	Screw, SCREW HOSE CLAMP HOSE		
22					SEE GROUP 4A
23					SEE GROUP 4A
24	955295	1	Screw		SEE GROUP 2A
25	941907	1	Spring washer		
26	834352	1	Clamp		
28	828023	1	Circulation pump Bulletin 41-13	41-13-EN	Hose Kit for Circulation Pump
28		?	· COMPONENTS		
29	924055	2	Stud		
30	463431	1	Gasket	IK	
31	1336255	1	Sealing ring	IK	(463430)
32	955892	2	Washer		
33	955781	2	Nut		
34	941906	4	Spring washer		
35	955275	4	Screw		
36	463629	1	Pulley		
37	463301	1	Washer		
38	946544	4	Flange screw		
39		1	V-BELT SET		SEE GROUP 3
40	430020	1	Sealing ring	IK 02B-0650	
41	831897	1	Tube	02B-0650	
42	831926	1	Connection pipe		
44	948564	1	Stud		L = 50 MM, SEE GROUP 2A

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
45	963196	2	Screw		MO 609/XXXX-7679500
	963197	2	Screw		L = 40 MM, MO 7679501-
45A	955892	2	Washer		MO 7679501-
46	875580	1	Thermostat kit	IK	80%Z9C
	875780		Thermostat kit	IK	75%Z9C
	875791		Thermostat kit	IK	55%Z9C
	875792		Thermostat kit	IK	56%Z9C
	875793		Thermostat kit	IK	55%Z9C
	875794		Thermostat kit	IK	62%Z9C
	875796		Thermostat kit	IK	60%Z9C
47	416033	1	· Sealing ring	IK	(418361)
48	955297	2	Screw		
49	941907	2	Spring washer		
50	925091	1	O-ring	IK	
51	955278	2	Screw		
52	941906	2	Spring washer		
53	831009	1	Cross piece		SEE GROUP 2A
54	828040	1	Bridge		SEE GROUP 2A
55	828035	1	· Bushing		SEE GROUP 2A
56	959230	2	Screw		SEE GROUP 2A
57	941907	2	Spring washer		SEE GROUP 2A
58	955282	1	Screw		SEE GROUP 2A
59	941906	1	Spring washer		SEE GROUP 2A
64		1	INDUCTION- AND EXHAUST MANIFOLD	02B-1750	