



9624

HYDRAULIC PUMP, TRIM INSTRUMENT AND INSTALLATION COMPONENTS

04A

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	852928	1	Hydraulic pump	
2		1	· MOTOR	
3		1	· PUMP HOUSING	
4	853085	1	· O-ring	
4A	852839	2	Hose	
4B	87698	2	· Nipple	
4C	954320	2	· Nut	
4D	940148	1	Screw	
4E	853215	2	Plug	
5	853020	1	Bracket	
6	955296	3	Screw	
7	941907	3	Spring washer	
8	955782	3	Nut	
9	852565	2	Relay	
10	956094	2	Screw	
11	949607	2	Spring washer	
12	955781	2	Nut	
13		X	CABLE AND CABLE TERMINALS	SEE GROUP 3
14	941905	4	Spring washer	
15	955844	4	Nut	
16	941907	4	Spring washer	
17	955834	4	Nut	
18	853067	1	Instrument panel	
18A		1	· CABLE UNIT	
18B		X	· · CABLES AND TERMINALS	SEE GROUP 3
18C	828731	1	· Trimmer	
18D	853866	1	· Control panel	
19	828647	4	· · Screw	
20	828739	1	· · Control panel	REPL BY 853866
21		X	· · CABLES AND TERMINALS	SEE GROUP 3
22	853545	1	· · Relay kit	
23	828584	1	· · Switch	
24	828586	1	· · Button	
25	828743	1	· · Button	
26	828742	1	· · Switch	
27	828740	2	· · Spacer washer	
28	853032	1	Cable trunk	
	948294	X	· Receptacle housing	9-POL
	965822	X	· Cable terminal	3,5X1X2,5
	853498	X	· Receptacle housing	3-POL
	853521	X	· Cable terminal	FOR 853498
29	949666	X	Strip clamp	