



3914

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	832682	1	Intermediate housing		
2	897829	1	· Gear yoke		
3	814397	1	· Coupling rod		
4	897447	1	· Shaft		
5	897511	2	· Washer		
6	17253	1	· Split pin		
7	925259	1	O-ring		
8	943866	X	Shim		TH = 0.1mm
	943867	X	Shim		TH = 0.2mm
	943868	X	Shim		TH = 0.4mm
9	875365	1	Fork		
10	940194	1	· Lubricating nipple		
11	814388	1	· Bushing		
12	183391	1	· Needle roller bushin		
13	181620	2	· Sealing ring		
14	941807	2	Hex. socket screw		
15	814390	2	Plastic washer		
16	941885	2	Lock nut		
17	897448	1	Control rod		
18	813954	1	Fork		
19	940190	1	Hexagon nut		
20	192662	1	Split pin		
21	17253	2	Split pin		
22	814386	1	Steering knuckle		
23	941820	1	O-ring		
24	897696	1	Washer		
25	941809	1	Hex. socket screw		
26	941808	2	Hex. socket screw		
27	851766	1	Hose connection		SEE GROUP 4A
28	814356	1	Sealing		
29	941813	2	Hex. socket screw		
30	897644	1	Tube		
31	125017	2	O-ring		
32		1	Cable attachment		
33	940168	2	Hexagon screw		
34	940191	2	Washer		
35		2	Bushing		
36	804312	1	Cube		
37	17276	1	Split pin		
38	940191	2	Washer		
39	814434	1	Reverse tilt inhibit		
40	814391	2	· Latch		
41	814389	1	· Bearing sleeve		
42	814422	2	· Spacer washer		
43	852046	1	· Push rod		(814421)
44	897722	1	· Thrust sleeve		
45	814394	1	· Lock brace		
46	814395	2	· Spindle		
47	832534	1	· Spring		
48	814399	1	· Shaft		
49	943194	1	· Washer		
50	814392	1	· Spring hook		LEFT
51	814419	1	· Shaft		
52	814393	1	· Spring hook		RIGHT.
53	943197	2	· Lock nut		
54	814398	1	· Spindle		
55	814396	1	· Spring		
56	814332	2	· Spring		
57	940197	1	· Hexagon nut		
58	941814	2	Stud	13132	
59		X	CONTROL CABLE		SEE GROUP 9
	875361	1	Repair kit, REPAIR KIT ASTERN LEVER		