



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	856364	1	Water pump		SEE GROUP 10A. INCLUDED IN BASIC ENGINE.
2	835210	2	· Gasket	IK	
3		1	· PUMP		REPL BY 856364
4	841036	1	· · Gasket	IK	
5	841209	1	· · Plate		
6	955511	6	· · Screw		
7	952358	1	· · Plug		
8	952359	1	· · Plug		
9	855283	1	Pulley		
10	955655	4	Screw		
11	941907	4	Spring washer		
12	940162	1	Screw		
13	955536	2	Screw		
14	955540	1	Screw		
15	834906	1	Hose		
16	961671	2	Hose clamp		
17	958498	1	V-belt		SEE GROUP 3
18	855722	1	Sea water pump		
				02B-0400	
19	968531	3	Screw		
20	942336	3	Spring washer		
21	826421	1	Bracket		
22	940115	2	Screw		
23	942336	2	Spring washer		
24	826422	1	Rubber bushing	IK	
25	955523	1	Screw		
26	960141	1	Washer		
27	941907	1	Spring washer		
28	826423	1	Hose		
29	961669	3	Hose clamp		
30	855374	1	Hose		
31	855567	1	Clamp		
	855568	1	Clamp		INSTALLS ON THE FLYWHEEL COVER.
32	841307	1	Clamp		
33	942336	1	Spring washer		
34	955534	1	Screw		
35	855485	1	Thermostat housing		
36	477026	1	· Expansion plug		(192426)
37	955537	2	Screw		
38	942336	2	Spring washer		
39	952970	X	Rubber hose		L = 2X350 MM
40	961666	4	Hose clamp		
41	961610	2	Hose nipple	02B-0185	
42	876305	1	Thermostat kit		(875794)
43	835417	1	· Gasket	IK	
44	416033	1	Sealing ring		
45	855486	1	Lock ring		