



9024

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	CYLINDER BLOCK		SEE GROUP 10A. INCLUDED IN BASIC ENGINE
2		4	· BEARING CAP		
3	835037	8	· Screw		
4	818989	2	· Locating pin		
4A	855828	1	· Locating pin		
5	835039	8	· Plug		
6	835040	2	· Locating pin		
7	835043	4	· Plug		
7A	952075	4	· Plug		
7B	856230		· Plug		
8	835040	2	· Locating pin		
9	835496	1	· Plug		
10	841423	2	· Bushing	02A-0385	
11	841424	1	· Bushing	02A-0385	
12	841422	1	· Bearing	02A-0385	
13	835497	4	· Locating pin		
14	856377	6	· Piston	02A-0285	
15	192134	3	· Plug		
16		3	· MAIN BEARING KIT	02A-0285	
16A	856408	1	Retainer		
16B	856409	2	Screw		
17	835977	1	Flywheel housing		REPLACED BY 1EA FLYWHEEL COVER 841967 AND 1EA GREASE NIPPLE 914167.
	841967	1	Flywheel housing		
17A	914167	1	Lubricating nipple		
18	826448	1	Cover plate		
19	947224	5	Screw		
20	941939	6	Screw		
21	942336	6	Spring washer		
22	841737	1	Valve		INCLUDED IN BASIC ENGINE