

DRIVE SP-A

PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
875192	1	Gasket kit, GASKET AND LOCKING KIT		
17253	2	• Cotter pin, CONTROL		
948209	1	• Locking wire		L = 300 MM
181620	2	• Sealing ring, FORK		
804261	3	• Gasket, PLUG		
897426	2	• Sealing ring, SHAFT		
897682	1	• Gasket, PLUG		
125017	2	• O-ring, INT. HOUSING		
925093	1	• O-ring, BEARING HOUSING		
925256	3	• O-ring, EXHAUST OUTLET		
925258	2	• O-ring, LOWER GEAR		
925259	1	• O-ring, INT. HOUSING		
942615	1	• Sealing ring, HOUSING		
941820	1	• O-ring, FORK		
958838	1	• Sealing ring, BEARING HOUSING		
951924	1	• Tensioning din, ECCENTRIC PISTON		
956000	1	• O-ring, HOUSING		
814168	1	• Gasket, HOUSING		
804344	1	• Gasket, BOLT		
814356	1	• Seal, HOSE UNION		
839195	1	• Ring, STEERING YOKE		
		• Bulletin 48-23	48-23-EN	Seal Ring
925261	2	• O-ring, HOUSING		
191573	1	• Lock washer, HOUSING		
814165	1	• Washer, HOUSING		
907023	1	• Lock washer, HOUSING		
907025	1	• Lock washer, HOUSING		
853670	1	• Sealing ring, HOUSING		
955989	1	• O-ring, HOLLOW BOLT		
832669	1	• Gasket, COVER		
832191	1	• Gasket, BALL BEARING		
925055	4	• O-ring		
814359	1	• Ring, STEERING YOKE		
955974	1	• O-ring, OIL PLUG		
814164	1	• Flange nut, SET OF GEARS		