



5972

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	832682	1	Intermediate housing	
2	897829	1	• Gear yoke	
3	814397	1	• Coupling rod	
4	897447	1	• Shaft	
5	897511	1	• Washer	
6	17253	1	• Split pin	
7	925259	1	O-ring	
8	967352	X	Shim	TH = 0,05 MM
	943866	X	Shim	TH = 0.1mm
	943867	X	Shim	TH = 0.2mm
	943868	X	Shim	TH = 0.4mm
9	875365	1	Fork	
10	940194	1	• Lubricating nipple	
11	814388	1	• Bushing	
12	183391	1	• Needle roller bushin	
13	181620	2	• Sealing ring	
14				
17	941885	2	Lock nut	
18	897448	1	Control rod	
19	813954	1	Fork	
20	940190	1	Hexagon nut	
21	192662	1	Split pin	
22	17253	2	Split pin	
23	814386	1	Steering knuckle	
24	941820	1	O-ring	
25	897696	1	Washer	
26	941809	1	Hex. socket screw	
27	941808	2	Hex. socket screw	
28	851766	1	Hose connection	SEE GROUP 4A
29	814356	1	Sealing	
30	941813	2	Hex. socket screw	
31				
33	897644	1	Tube	
34	125017	2	O-ring	
35		1	Cable attachment	
36	940168	2	Hexagon screw	
37	940191	2	Washer	
38		2	Bushing	
39	804312	1	Cube	
40	907834	1	Split pin	(17276)
41	940191	2	Washer	
42	814434	1	Reverse tilt inhibit	
43	814391	2	• Latch	
44	814389	1	• Bearing sleeve	
45	814422	2	• Spacer washer	
46	852046	1	• Push rod	(814421)
46B		1	• • NUT	(940197)
47	897722	1	• Thrust sleeve	
48	814394	1	• Lock brace	
49	814395	2	• Spindle	
50	832534	1	• Spring	
51	814399	1	• Shaft	
52	943194	1	• Washer	
53	814392	1	• Spring hook	
54	814419	1	• Shaft	
55	814393	1	• Spring hook	
56	943197	2	• Lock nut	
57	814398	1	• Spindle	
58	814396	1	• Spring	
59	814332	2	• Spring	
60		X	CONTROL CABLE	SEE GROUP 9
61	941807	2	Hex. socket screw	
	875361	1	Repair kit, REPAIR KIT ASTERN LEVER	