



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	841377	1	Starter motor		REPL BY 855334
	855334	1	Starter motor, STARTER MOTOR COMPS NOT SPEC.	030-0450	
2	940134	2	Screw		
3	941909	2	Spring washer		
4	955827	1	Nut		
	940179	2	Nut		
5	841177	1	Relay		
6		1	ALTERNATOR AND INSTALLATION COMPONENTS	030-0192	
7	958497	1	V-belt		
8	835630	1	Temperature sensor		SEE GROUP 2B
	835649	1	Sender		SEE GROUP 9. FOR FLYING BRIDGE.
9	841598	1	Thermo monitor		SEE GROUP 2A
10	841069	1	Distributor		(834855)
				030-0200	
11	835154	1	Gasket	IK	
12	841530	1	Clamp		
13	955535	1	Screw		
14	941744	1	Washer		
15	841228	2	Ignition cable		CYL 1,2
	841227	2	Ignition cable		CYL 3,4
	841226	2	Ignition cable		CYL 5,6
	841225	2	Ignition cable		CYL 7,8
16	855674	1	Ignition cable		
17	876047	2	Spark plug kit		
18	835998	1	Ignition coil		
19	834772	2	Nut		
20	834700	1	Bracket		SEE GROUP 2D
21	1219561	1	Clamp		
22	834371	1	Screw		
23	835999	1	Resistor		
24	834784	1	Resistor		
25		1	NIPPLE		REPL BY 841891. MO 15712-19205.
	841891	1	Nipple		
26	16325	1	Plug		MO 15712-19205.
27	834920	1	Oil pressure sensor		
	834921	1	Oil pressure sensor		(835651). FOR FLYING BRIDGE.
28	841599	1	Pressure monitor		MO15712-
29	841178	1	Fuse		40A
30	950013	2	Screw		
31	841822	1	Cable trunk		
32		X	CABLE AND TERMINALS	030-0625	
33	955511	1	Screw		(835369)
34	835671	X	Cable trunk		L = 3000 MM. FOR INSTRUMENT PANEL 841094 AND 841095.
	835670	X	Cable trunk		L = 6000 MM. FOR INSTRUMENT PANEL 841096 AND 841097.
35	841095	1	Instrument panel		
				030-0500	
	841211	1	Panel		EUR
				030-0550	
36	948210	X	Strip clamp		
37	835429	2	Retainer		
38	835428	2	Retainer		
39	955511	2	Screw		(835369)

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
40	835427	2	Retainer		