



9112

DRIVE SP-A/MT

REF	PART NO.	QTY	DESCRIPTION		NOTES
1	854027	1	Intermediate housing		
2	897829	1	• Gear yoke		
3	814397	1	• Coupling rod		
4	897447	1	• Shaft		
5	897511	1	• Washer		
6	17253	1	• Cotter pin		
7	925259	1	O-ring	IK	
8	943252	X	Adjusting washer		TH = 0,05 MM
	943866	X	Adjusting washer		TH = 0,1 MM
	943867	X	Adjusting washer		TH = 0,2 MM
	967557	X	Adjusting washer		TH = 0,30 MM
	943868	X	Adjusting washer		TH = 0,4 MM
9	876168	1	Suspension fork		
10	940194	1	• Nipple		
11	814388	1	• Bushing		
12	183391	1	• Needle bearing		
13	181620	2	• Sealing ring	IK	
13A	853717	1	• Decal		
13B	853716	1	• Decal		
14	959456	2	Allen head screw		
15	942551	2	Washer		
16	814390	2	Washer		ALT
17	941885	2	Nut		
18	897448	1	Control rod		
19	813954	1	Control fork		
20	940190	1	Nut		
21	192662	1	Clevis pin		
22	17253	2	Cotter pin	IK	
23	814386	1	Tube		
24	941820	1	O-ring	IK	
25	897696	1	Washer		
26	941809	1	Screw		
27	941808	2	Screw		
28	854031	1	Hose connection		SEE GROUP 4A
29	814356	1	Seal	IK	
30	941813	2	Screw		
33	897644	1	Tube		
34	125017	2	O-ring	IK	
35	897457	1	Cable attachment		
36	940168	2	Screw		
37	940191	2	Washer		
38	826341	2	Bushing		
39	804312	1	Cube		
40	907834	1	Cotter pin		
41	940191	2	Washer		
42	854030	1	Reverse tilt inhibit		
43	814391	2	• Reverse tilt inhibit		
44	814389	1	• Bearing sleeve		
45	814422	2	• Spacer washer	IK	
46	852046	1	• Push rod		
46B		1	• • NUT		
47	897722	1	• Thrust sleeve		
48	814394	1	• Lock brace		
49	814395	2	• Pin		
50	832534	1	• Spring	IK	
51	814399	1	• Shaft	IK	
52	943194	1	• Washer	IK	
53	814392	1	• Spring hook	IK	
54	814419	1	• Shaft	IK	
55	814393	1	• Spring hook	IK	
56	943197	2	• Nut	IK	
57	814398	1	• Shaft	IK	
58	814396	1	• Spring	IK	

