



| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|---------------------|----------|---|
| 1 | 841350 | 1 | Cylinder block | | MO-15153 |
| | 841827 | 1 | Cylinder block | | MO15154- |
| 2 | | 5 | · BEARING CAP | | |
| 3 | 835037 | 5 | · Screw | | |
| 5 | 835038 | 5 | · Stud | 02A-0600 | |
| 6 | 818989 | 2 | · Locating pin | | |
| 7 | 835039 | 8 | · Plug | | |
| 8 | 835040 | 2 | · Locating pin | | |
| 9 | 835043 | 4 | · Plug | | |
| 10 | 835040 | 2 | · Locating pin | | |
| 11 | 952075 | 5 | · Plug | | |
| 12 | 835496 | 1 | · Plug | | |
| 13 | 841423 | 2 | · Bushing | 02A-0400 | |
| 14 | 841424 | 2 | · Bushing | 02A-0400 | |
| 15 | 841422 | 1 | · Bearing | 02A-0400 | |
| 16 | 835497 | 4 | · Locating pin | | |
| 17 | 191026 | 1 | · Plug | | (952069) |
| 18 | 826467 | 8 | · Piston | 02A-0300 | |
| 19 | 940133 | 1 | · Screw | | |
| 20 | 18651 | 1 | · Gasket | | |
| 21 | 192134 | 2 | · Plug | | |
| 22 | | X | · MAIN BEARING KIT | 02A-0300 | |
| 23 | 835977 | 1 | Flywheel housing | | REPLACED BY 1EA FLYWHEEL COVER 841967 AND 1EA GREASE NIPPLE 914167. |
| | 841967 | 1 | Flywheel housing | | |
| 23A | 804262 | 1 | Plug | | EARLY TYPE |
| | 914167 | 1 | Lubricating nipple | | LATE TYPE |
| 24 | 826448 | 1 | Cover plate | | |
| 25 | 947224 | 5 | Screw | | |
| 26 | 941939 | 6 | Screw | | |
| 27 | 942336 | 6 | Spring washer | | |
| 28 | | | SCREW | | EXCL AQ260A |
| 29 | | | SPACER SLEEVE | | EXCL AQ260A |
| 30 | | | SCREW | | EXCL AQ260A |
| 31 | | | SPACER SLEEVE | | EXCL AQ260A |
| 32 | | | PLUG | | EXCL AQ260A |
| 33 | | | ENGINE NUMBER PLATE | | |