

REF	PART NO.	QTY	DESCRIPTION	NOTES
1121	3856766	1	Nipple, TBI nipple, front	NOTES
1	3852034	1	Retainer, Float pin	
2	3854152	1	Valve, Reservoir assy	
3	3852462	1	Fitting, Fuel line to reservoir	
5	3852481	1	Grommet, Fuel pump to cover	Reservoir assy
6	3852017	1	Adapter, Fuel line	LP pump to reservoir
7	3853642	2	O-ring, Retainer, fuel pump	Part of engine gasket kit
8	3853572	1	Hollow screw, Fuel pump to cover	Reservoir assy
9	3853573	1	Bracket, Fuel pump grommet	Reservoir assy
10	3857728	1	Gasket, Cover	Reservoir assy
11	3853575	1	Float, Reservoir assy	
12	3853576	1	Seat, Float needle	Reservoir assy
13 14	3853577 3853578	1	Gasket, Float needle seat Needle, Float	Reservoir assy Reservoir assy
15	3853579	1	Clip, Needle to float	Reservoir assy
16	3853597	1	Elbow, Vent, reservoir to intake	ixeservoir assy
17	3852480	1	Riser, Reservoir to thermostat hsg	
18	3853606	8	Screw, Cover to reservoir	Reservoir assy
19	3853616	2	Protective cap, Pressure valve	
20	3857650	1	Fuel pump, High pressure	
21	3854149	1	Tank	
23	3852167	1	Plug, Reservoir drain	
24	3856438	1	Bracket, Fuel filter and fuel pump	
26	3854405	1	Cover, Reservoir assy	
27	3852001	2	Lock washer, Circuit breaker	
28	3853310	1	Bracket, Fuel filter	
29 30	3853326	2	Screw, Bracket to engine	
31	3852013 3852064	2	Riser, Inlet, fuel filter cover Nut, Circuit breaker	
32	3852208	2	Screw, Relay & cable assy	
34	3853620	2	Screw, Circuit breaker to bracket	Electrical ignition
35	3852481	1	Grommet, Fuel pump to bracket	Licetifeat ignition
38	3850861	1	Cover	
39	3851218	1	• Fuel filter	
40	3853494	1	Fitting, Fuel line to fuel pump	
41	3850820	2	· O-ring, Fitting	
43	3858261	1	Fuel pump, Low pressure	
44	3854163	1	Breaker, 12.5A	
50	3850278	1	Fuel pipe, TBI to reservoir	
51	3856534	1	Fuel line, LP pump to reservoir	
55	3853266	2	Screw, Fuel filter to bracket	
64	3853616	1	Protective cap, Pressure valve	
67	3857533 3853493	1	Relay, Fuel pump Fitting, Fuel pump to fuel filter cover	
68	3850819	1	O-ring, Filting, fuel pump to cover	Fuel filter
71	3852210	1	Bracket, Relay	. doi intoi
73	3853494	1	Fitting, HP fuel pump	
76	3850374	1	Sealing kit, Fuel reservoir	
77	3853537	2		
78	3853261	1	Clamp, Oil withdrawal tube to fuel filter brkt	
79	3852129	1	Nut, Screw, fuel filter assy to bracket	
82	3853794	4		
83	943367	1	Hose, Thermostat hsg to reservoir	
88	3854763	1	Reservoir to flywheel hsg	
90	3850277	1	Fuel pipe, HP fuel pump to TBI	
91	3850657 3852957	1	Nut, Reservoir & bracket to flywheel hsg Screw, Reservoir & bracket to flywheel hsg	
92	3852957	1	Screw, Reservoir & bracket to hywneel risg	
93	3854896	1	Clamp, Fuel line to bracket	
95	3852170	1	Clamp, Hose to pulse limiter	
96	3852529	1	Clamp, Hose to pulse limiter	
97	3852503	1	Elbow, Pulse limiter to adapter	
98	3850689	1	Hose, Reservoir to pulse limiter	
99	3852129	1	Nut, Oil tube to bracket	

7797510 - - 0-0014 GR980671 Upd: 20 FEB 2006

RFF	PART NO.	OTY	DESCRIPTION	NOTES
100	3854897	4 1	Screw, Clamp to bracket	NOTES
102	3854820	1	Bracket, Fuel line clamp	
104	3853262	1	Screw, Bracket, flywheel hsg to engine	
105	3850423	1	O-ring Fuel line to fuel regulator	
106	3850424	1	O-ring, Fuel line to fuel regulator O-ring, Fuel line to fuel rail	
107	3852225	1	Impulse limiter	
111	3856449	1	Fitting, Reservoir, port nipple	
113	943367	1	Hose, Reservoir to riser	
115	3853598	2	Riser, Riser, thermostat housing	
	10 - - 0-001			
		4	GR980671	Upd: 20 FEB 200