



COOLING

| REF | PART NO. | QTY | DESCRIPTION | NOTES |
|-----|----------|-----|---|---------------------------|
| 1 | 3860162 | 1 | Hose, Sea water pump to thermostat hsg | |
| 2 | 3853780 | 2 | Clamp, Hose to elbow, exhaust manifold | |
| 3 | 3857391 | 1 | Hose, Thermostat hsg to circulation pump | |
| 4 | 3852098 | 2 | Clamp, Hose, thermostat hsg to water pump | |
| 5 | 3860283 | 1 | Thermostat housing | |
| 6 | 3853799 | 1 | Thermostat | |
| 7 | 3856537 | 1 | O-ring, Thermostat | |
| 8 | 3852096 | 1 | Gasket, Therm hsg to cylinder head | Part of engine gasket kit |
| 9 | 3852029 | 1 | Sender, Water temperature | |
| 10 | 3853266 | 1 | Screw, Therm. hsg to engine | |
| 11 | 3850116 | 1 | Hose, Thermostat hsg to base carburetor | ½-in. I.D. |
| 12 | 3858855 | 2 | Fitting, Thermostat hsg to base of carb | |
| 13 | 3853780 | 2 | Clamp, Hose, thermostat hsg to base of carb | |
| 14 | 3853780 | 2 | Clamp, Hose, therm hsg to exhaust manifold | |
| 15 | 3853342 | 1 | Gasket, Water pump | Part of engine gasket kit |
| 16 | 3858340 | 1 | Coolant pump | |
| 17 | 3853167 | 2 | Screw, Water pump | |
| 18 | 3852063 | 2 | Screw, Water pump | |
| 19 | 3857647 | 1 | Pulley, Water pump | |
| 20 | 3860348 | 4 | Screw, Water pump pulley to hub | |
| 21 | 3857823 | 2 | Hose, Thermostat hsg to riser | |
| 22 | 3852538 | 1 | Elbow, Water hose to riser | |
| 23 | 3852172 | 2 | Clamp, Hose, thermostat hsg to manifold | |
| 24 | 3857822 | 1 | Fitting, Thermostat hsg hose to riser | |
| 25 | 3851592 | 1 | Hose, Thermostat hsg to exhaust manifold | |
| 26 | 3852538 | 1 | Elbow, Water hose to exhaust manifold | |