



COOLING, GL

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3852602	2	Clamp, Hose to thermostat housing	
2	3853780	4	Clamp, Hose them hsg to exhaust manifold	
3	3853391	1	Screw, Alignment bracket & thermostat hsg	
4	3852649	1	Bracket, Alignment bracket	
5	3853401	1	Screw, Thermostat hsg to engine	
6	3850360	1	Thermostat housing, Thermostat hsg	
7	3857843	2	Hose, Thermostat hsg to manifold	Cut to length; port
8	3858237	1	Hose, Pump to thermostat hsg	
9	3858235	1	Hose, Cooler to pump	
10	3853786	2	Clamp, Hose, water pump inlet	
11	3852477	2	Gasket, Water pump to block	Part of engine gasket kit
12	3850595	1	Gasket, Water pump cover	
13	3853850	1	Coolant pump	
14	3856147	2	Stud, Water pump	
15	3850397	1	Ect sensor	
16	3857939	3	Screw, Water pump pulley to engine	
17	3853390	4	Screw, Water pump pulley to hub	
18	3852220	1	Pulley, Water pump	
19	3856136	1	Screw, Water pump, short	
20	3858229	1	Sea water pump	
21	3852071	1	O-ring, Thermostat	Part of engine gasket kit
22	3852098	2	Clamp, Hose, thermostat hsg to water pump	
23	3856961	1	Thermostat, Engine	
24	3852111	1	Gasket, Thermostat hsg to engine	
25	3852288	1	Hose, Thermostat hsg to water pump	
26	3853598	1	Riser, Thermostat hsg	
27	3852507	1	Stud, P/S bracket, pump	
28	3858241	1	Bracket, Stay, sea water pump	
29	3857954	1	Stop, Stay, sea water pump	
30	3853266	2	Screw, Stay bracket to engine	