

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	834692	1	Starter alternator		
2		1	· HOUSING		
3		4	· POLE SHOE		
4	243329	4	· Screw		
5	834876	1	· Field winding		
6	834877	1	· Field winding		
7	834878	1	· Field winding		
8	834879	1	· Field winding		
9	834880	1	· Screw		
10	870126	1	· Isolation		
11	870127	1	· Insulating bushing		
12	241331	1	· Washer		TH = 0,6 MM
13	239568	2	· Washer		TH = 1,0 MM
14	941907	2	· Spring washer		
15	955782	2	· Nut		
17	870130	1	· Cable		
18		X	· CABLES AND TERMINALS	030-1350	
19	238832	1	· Screw		
20	870132	1	· Screw		
21	240157	2	· Isolation		
22	243064	4	· Washer		
23	941905	4	· Spring washer		
24	955780	4	· Nut		
27	100066	1	· Screw		
28	941905	1	· Spring washer		
29	906822	1	· Washer		
30	243332	1	· Bearing shield		
31	241217	8	· Screw		
32	241294	8	· Washer		
33	870137	1	· End plate		
34	243335	4	· Carbon holder		
35		2	· BASE PLATE		
36	77508	2	· Isolation plate		
37		4	· INSULATING WASHER		
38	72492	4	· Washer		
39	870141	2	· Local part		
40	243337	8	· Rivet		
41	870840	1	· Carbon brush set		
42	870144	4	· Spring		
43	956059	4	· Screw		
44	241294	4	· Washer		
45	241217	8	· Screw		
46	241294	8	· Washer		
47	870146	1	· Rotor		
48	77680	1	· Washer		
49	870147	1	· Washer		
50	243340	1	· Ball bearing		
51	233563	1	· Washer		
52	870149	1	· Washer		
53	870150	1	· Washer		
54	233775	1	· Safety washer		
55	11009	1	· Ball bearing		
56	956167	4	· Screw		
57	910115	1	· Key		
58	941911	1	· Spring washer		

