



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	855074	1	Intermediate housing		
2	946541	4	Screw		
3	855234	1	Screw		(855199)
4	955981	1	O-ring		
5	855203	2	Sealing ring		(3551500)
6	3555315	1	Bushing		
7	855202	2	Sealing ring		(3551486)
8	855105	1	Corrosion protection		
9	963683	1	Screw		
10	3555903	1	Bushing		
11	855126	1	Gear rod		
12	855044	1	Axle shaft		
13	855212	1	Key		
14	3553295	2	Needle bearing		
15	3551683	1	Bearing race		
16	3553294	1	Needle bearing		
17	3552694	1	Washer		
18		1	PINION		(3574628). REPLACED BY GEAR SET 3576122.
19	855077	1	Gasket	04C-0300	
20	3555905	1	Gear selector		
21	925064	1	O-ring		
22	3555397	1	Pump housing		SEE GROUP 2B
23	3555414	1	Plate		SEE GROUP 2B
24	963684	4	Screw		
25	963694	2	Screw		SEE GROUP 2B
26	3554880	1	Bushing		SEE GROUP 2B
27	855123	1	Compression spring		
28	855127	1	Lever		SEE GROUP 2D
29	804312	1	Cube		SEE GROUP 2D
30	940191	1	Washer		SEE GROUP 2D
31	907834	1	Cotter pin		(17276) SEE GROUP 2D
32	855043	4	Bushing		
33	855079	1	Splined sleeve		
34	3555298	1	Bushing		
35	955966	1	Snap ring		
36	855133	1	Adjusting washer		