



FUEL PUMP & FILTER

| REF | PART NO. | QTY | DESCRIPTION | NOTES |
|-----|----------|-----|-------------------------------|------------------|
| 1 | 3853558 | 2 | Screw, Bracket to head | |
| 2 | 3853379 | 1 | Bracket, Fuel filter | |
| 3 | 3850861 | 1 | Cover | |
| 4 | 3851218 | 1 | · Fuel filter | |
| 5 | 3852014 | 1 | Fitting, Fuel inlet | |
| 6 | 3852702 | 1 | Fitting, Fuel line to filter | |
| 7 | 3852525 | 2 | Fitting, Fuel pump | |
| 8 | 3854059 | 1 | Fuel pipe, Pump to Garb | 5.0 Litre Models |
| | 3854058 | 1 | Fuel pipe, Pump to Garb | 5.8 Litre Models |
| 9 | 3854039 | 1 | Fuel pipe, Filter to pump | 5.0 Litre Models |
| | 3854024 | 1 | Fuel pipe, Filter to pump | 5.8 Litre Models |
| 10 | 3854053 | 1 | Fuel pump | |
| 11 | 3852095 | 1 | Gasket, Fuel pump | |
| 12 | 3854242 | 1 | Hose, Overflow, pump to carb | |
| 13 | 3852158 | 2 | Lock strap, Overflow hose | |
| 14 | 3852486 | 3 | Lock strap, Hose to fuel line | |
| 15 | 3853261 | 1 | Clamp, Fuel line | |
| 16 | 3853326 | 2 | Screw, Fuel pump to engine | |
| 17 | 3853557 | 2 | Screw, Filter to bracket | |