



DISTRIBUTOR & IGNITION COIL, Gi

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3850399	1	Distributor	
2	3855596	1	· Shaft, Distributor	
3	3854548	1	· Distributor cap, Distributor	
4	3854549	1	· Rotor, Distributor	
5	3854003	1	· Module, Distributor	
6	3854001	1	· Coil	
7	3854552	1	· Shield, Distributor	
8	3853317	1	· Retainer, Distributor	
9	3853316	1	· Locating pin, Distributor	
10	3853318	1	· Screw, Distributor cap	
11	3853319	1	· Screw, Module	
12	3854557	1	· Repair kit	
	960148	2	· · Washer, Coil to bracket	
		1	· · GEAR	
		1	· · TANG WASHER	
13	3855597	1	· Housing	
14	3854267	X	· Pole shoe	
15	3850429	1	Bracket, Ignition coil to flywheel hsg	
16	3852051	2	Nut, Ignition coil to bracket	INCSCE, PNCACE, PNCMCE only
	3852064	2	Nut, Coil terminal	INCCCE, PNCBCE, PNCSCE, PNCS only
17	3854084	1	Cable, Distributor to ignition coil	
18	3851820	1	Ignition cable kit, Spark plug wire	INCSCE, PNCACE, PNCMCE only
	3851819	1	Ignition cable kit, Spark plug wire	INCCCE, PNCBCE, PNCSCE, PNCS only
19	3852491	2	· Retainer, 4 wire	
20	3852492	2	· Retainer, 3 wire	
21	3853547	1	Screw, Coil bracket	
22	3852827	2	Bracket, Lead retainer, rear, port & starboard	
23	3854002	1	Ignition coil	INCSCE, PNCACE, PNCMCE only
	3852217	1	Ignition coil	INCCCE, PNCBCE, PNCSCE, PNCS only
24	3852619	2	Retainer, Clamp, rear ignition leads, 4 wire	