



CRANKCASE, FL

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	3855165	1	Longblock,		
			Bulletin P-21-0-7	P-21-0-7-EN	Longblock guidelines, 5.0L, 5.8L, Ford
2	3853007	4	Guide sleeve, Cylinder head to block		
3	3852650	6	Cap plug, Core hole		
4	3853008	2	Cap plug, Oil passage		
5	3853108	6	Plug, Oil gallery		
6	3853008	2	Cap plug, Indicator hole		
7	3852766	1	Cap plug, Rear, cam, standard		
	3853009	X	Cap plug, Rear cam, 0.060 in. OS		
8	3853076	1	Locating pin, Adapter hsg to block		
9	3853101	9	Screw, Main bearing cap		
10	3853102	1	Stud, Main bearing cap		
11	3853026	1	Nut, Main bearing cap		
12	3853010	1	Cap plug, Rear hole in block		
13	3852793	1	Crankshaft, 235 model		
14	3853268	4	Piston ring kit, Standard		Contains Rings for 2 Pistons
	3853269	X	Piston ring kit, 0.020 in. OS		Contains Rings for 2 Pistons
	3853270	X	Piston ring kit, 0.030 in. OS		Contains Rings for 2 Pistons
	3853271	X	Piston ring kit, 0.040 in. OS		Contains Rings for 2 Pistons
15	3853898	X	Piston, Standard, red		
	3853949	X	Piston, 0.020 in. OS		
	3853950	X	Piston, 0.030 in. OS		
	3853951	X	Piston, 0.040 in. OS		
16	3852773	8	Piston pin, Piston, standard		
17	3852774	16	Rod bearing, Connecting rod, standard		
	3853081	X	Rod bearing, Connecting rod, 0.010 in. US		
	3853082	X	Rod bearing, Connecting rod, 0.020 in. US		
	3853083	X	Rod bearing, Connecting rod, 0.030 in. US		
18	3850393	8	Connecting rod		
19	3852675	16	Nut, Connecting rod		
20	3852674	16	Screw, Connecting rod		
21	3852779	1	Camshaft		
22	3852801	8	Main bearing, Main, standard, upper		
			Bulletin P-21-6-1	P-21-6-1-EN	Main Bearing Kits, 5.0 and 5.8L Ford
22	3853086	X	Main bearing, Main, 0.010 in. US, upper		
	3853087	X	Main bearing, Main, 0.020 in. US, upper		
	3853088	X	Main bearing, Main, 0.030 in. US, upper		
23	3852802	8	Main bearing, Main, standard, lower		
			Bulletin P-21-6-1	P-21-6-1-EN	Main Bearing Kits, 5.0 and 5.8L Ford
23	3853092	X	Main bearing, Main, 0.020 in. US, lower		
	3853093	X	Main bearing, Main, 0.030 in. US, lower		
	3853091	X	Main bearing, Main, 0.10 US, lower		
24	3852803	2	Thrust bearing, Main, center, standard		
			Bulletin P-21-6-1	P-21-6-1-EN	Main Bearing Kits, 5.0 and 5.8L Ford
24	3853096	X	Thrust bearing, Main, center, 0.010 in. US		
	3853097	X	Thrust bearing, Main, center, 0.020 in. US		
	3853098	X	Thrust bearing, Main, center, 0.030 in. US		
25	3852780	1	Camshaft bearing, Camshaft, front		
	3853018	X	Camshaft bearing, Front, 0.015 in. US		
26	3852781	1	Camshaft bearing, Camshaft, center		
	3853019	X	Camshaft bearing, Center, 0.015 in. US		
27	3852782	1	Camshaft bearing, Camshaft, rear		
	3853020	X	Camshaft bearing, Rear, 0.015 in. US		
28	3852783	1	Camshaft bearing, Camshaft		
	3853022	X	Camshaft bearing, Front intermediate, 0.015 in. US		
29	3853023	X	Camshaft bearing, 0.015 in. US		
	3852784	1	Camshaft bearing, Camshaft, rear intermediate		
30	3852788	2	Screw, Camshaft, thrust plate		
31	3852791	1	Screw, Camshaft sprocket		
32	3856737	1	Chain		
33	3852796	1	Key, Sprocket to crankshaft		
34	3852790	1	Washer, Camshaft sprocket		
36	3852786	1	Locating pin, Camshaft sprocket		
37	3852806	1	Seal, Crankshaft, rear		

CRANKCASE, FL

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
38	3855197	1	Vibration damper, Crankshaft		
39	3853021	1	Screw, Crankshaft damper		
40	3852673	1	Guide, Fuel pump, outer		
41	3852789	1	Guide, Fuel pump, inner		
43	3852787	1	Thrust plate, Camshaft thrust, standard		
	3853024	X	Thrust plate, 0.002 in. OS, camshaft thrust		
	3853025	X	Thrust plate, 0.004 in. OS, camshaft thrust		
44	3853893	1	Timing gear casing, Cylinder front		
45	3852768	1	Turn signal, Timing		
46	3853035	1	Insert, Oil filter		
47	3853952	1	Flywheel		
48	3852804	1	Gear ring, Flywheel		
49	3853827	1	Seal, Front cover		
50	3853078	1	Clamp, Distributor		
51	3853077	1	Screw, Clamp		
52	3853273	6	Lock nut, Flywheel & coupler to crankshaft		SX, DP-S
52a	3854496	6	Washer, Dampener to flywheel		290 DP
	3854497	6	Lock nut, Dampener to flywheel		290 DP
54	3853862	1	Rubber coupling, Flywheel		SX, DP-S
	3850520	1	Vibration damper, Flywheel		290 DP
55	3853274	6	Stud, Flywheel & coupler to crankshaft		SX, DP-S
	3854495	6	Stud, Dampener to flywheel		290 DP
56	3853003	1	Cover		
57	835779	1	Oil filter		
58	3852421	5	Screw, Flywheel cover to hsg		
59	3854494	2	Drain cock, Engine water drain		
60	3855088	1	V-belt pulley, Crankshaft		
61	3853800	1	Oil pressure sensor, Oil pressure		
	872064	1	Sender, Oil pressure, dual station		
62	3852767	1	Gasket, Front cover		
63	3853011	X	Screw, Front cover		
	3853012	X	Screw, Front cover		
	3853013	X	Screw, Front cover		
	3853014	X	Screw, Front cover		
64	3853075	1	Washer, Crankshaft damper		
65	3853557	4	Screw, Pulley to crankshaft		
66	3852712	1	Nipple, Oil pressure sending unit		
67	3852711	1	Fitting, Oil pressure sending unit		
68	3850412	1	Bushing, Pilot, Crankshaft		DP
69	3855532	8	Screw, Flywheel to crankshaft, 290 DP		