


FUEL PUMP & INTAKE MANIFOLD, GL



FUEL PUMP & INTAKE MANIFOLD, GL

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3854100	1	Inlet pipe	
2	3850861	1	Cover	
3	3851218	1	· Fuel filter	
4	3854096	1	Gasket kit, Intake manifold	
5	3853539	12	Screw, Intake manifold to head	INCS, PNCA only
	3855983	7	Screw, Intake manifold to head	INCC, PNCA, PNCS only
	3855984	1	Screw, Intake manifold to head	INCC, PNCA, PNCS only
	3854653	2	Screw, Intake manifold to head	INCC, PNCA, PNCS only
6	3852109	1	Gasket, Distributor	
7	3852108	1	Clamp, Distributor to engine	
8	3854710	1	Breaker, Water temp, intake manifold	
9	3853537	2	Protective cap, Breaker assy, fuel pump	
10	3854902	1	Fuel pump	
11	3854162	1	Breaker, 12.5A	
12	3853494	1	Fitting, Fuel line to fuel pump	
13	3850820	2	O-ring, Fuel line to fuel pump, carburetor	
14	3853373	4	Stud, Carburetor mounting	
15	3853493	1	Fitting, Fuel pump to fuel filter cover	
16	3850819	1	O-ring, Fitting, fuel pump to cover	Fuel filter
17	3852118	1	Nut, Anchor, throttle cable to bracket	
18	3852048	1	Screw, Anchor, throttle cable to bracket	
19	3850227	1	Bracket, Throttle cable to manifold	
20	3852086	2	Screw, Bracket, throttle anchor	To intake manifold
21	3852117	1	Stud, Lift bracket & fuel pump bracket	To head, front, stbd
22	3853404	1	Lock nut, Lift bracket	
23	3854074	1	Fuel pipe, Fuel pump to carburetor	
24	3852666	1	Plug, Intake manifold	
25	3853620	2	Screw, Circuit breaker to bracket	
26	3853169	X	Sealant, Manifold ends	
27	3852458	1	Clamp, Dil withdrawal tube to fuel filter bracket	
28	3852129	1	Nut, Clamp, oil withdrawal tube	To fuel filter bracket
29	3852077	2	Nut, Relay & cable to bracket	
30	3852208	2	Screw, Relay & cable assy	To electric FIP bracket
31	3854376	1	Bracket, Fuel filter and fuel pump	
32	3850996	1	Lift	
33	3850266	1	Anchorage, Throttle cable	
35	3852013	1	Riser, Inlet, fuel filter cover	
36	3853326	2	Screw, Fuel filter assy to bracket	
37	3852481	1	Grommet, Fuel pump	
38	3853557	1	Screw, Distributor clamp to engine	
39	3852064	2	Nut, Circuit breaker	
40	3853273	1	Lock nut, Stud	
	3854075	1	Relay kit, Fuel pump	Not shown
41	3853681	1	· Cover, Fuel pump	
42	3852210	1	· Bracket, Fuel pump relay	
43	3852259	1	· Relay	
44	3854088	1	· Cable, Fuel pump	
45	3852240	1	Connector	
46	3852235	1	Cable terminal	
47	3852246	3	· Cable terminal	
48	3852247	1	· · Cable terminal	
49	3852229	3	· · · Cable terminal	
50	3852258	1	· · · Diode	
51	3852260	1	· Connector, Fuel pump	
52	3853679	2	· Cable terminal, Fuel pump	
54	3852237	1	Retainer, Cable	
55	3854117	1	Cable	
56	3852239	1	· Pin connector	
57	3852257	3	· Cable terminal	
58	3852235	1	· Cable terminal	
60	3852198	1	· Connector	
61	3852001	6	Lock washer, Circuit breaker	DP, IB
	3852001	8	Lock washer, Circuit breaker	SX, DP-S
62	3852093	1	Stud, Lift bracket	

7797250 - - 0-0015

GR950331

Upd: 22 NOV 2005

NC 7.4 GL, 7.4 Gi, 7.4 Gsi; 8.2 Gsi

VOLVO
PENTA

