


ENGINE WIRE HARNESS BRACKET



ENGINE WIRE HARNESS BRACKET

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3854162	1	Breaker, 12.5 amp	ECM; Gi
	3854163	1	Breaker, 20 amp	Fuel pumps; Gi
	3854164	2	Fuse, 50 amp	Main pump; trim pump
	3854238	1	Fuse, 6 amp	Fuel pumps; GL/GS
2	3852182	1	Lock washer, Nut to circuit breaker bracket	Isolator
3	3852064	6	Nut, Circuit breaker terminals	
4	3853620	6	Screw, Circuit breaker to bracket	
5	3852001	6	Lock washer, Circuit breaker terminals	
6	3852825	1	Retainer, Engine cable	
7	3852208	3	Screw, Retainer, engine cable end to bracket	
8	3854138	1	Relay, Starter motor	
9	3850234	1	Isolation, Relay mounting	
10	3852118	2	Nut, Relay to isolator	
11	3855938	4	Screw, Circuit breaker cover to bracket	
12	3856186	1	Bracket, Circuit breaker & engine cable	
13	3856764	1	Cover, Circuit breaker bracket	
14	941263	2	Grommet, Circuit breaker bracket	