



4150

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	842549	1	Stop solenoid	D42A PP SPEC. 16053, 867638.
2	842547	1	Bracket	D42A PP SPEC. 16053, 867638.
3	823575	1	Spacer sleeve	L = 6 MM. D42A PP SPEC. 16053, 867638.
4	940115	1	Screw	L = 25 MM. D42A PP SPEC. 16053, 867638.
	955534	1	Screw	L = 19 MM. D42A PP SPEC. 16053, 867638.
5	942336	2	Spring washer	D42A PP SPEC. 16053, 867638.
6	955826	2	Nut	D42A PP SPEC. 16053, 867638.
7	941907	2	Spring washer	D42A PP SPEC. 16053, 867638.
8	821134	1	Lever	D42A PP SPEC. 16053, 867638.
9	842546	1	Attaching plate	D42A PP SPEC. 16053, 867638.
10	955856	2	Nut	D42A PP SPEC. 16053, 867638.
11	941906	1	Spring washer	D42A PP SPEC. 16053, 867638.
12		2	ATTACHMENT	D42A PP SPEC. 16053, 867638.
13	819809	1	Tension spring	D42A PP SPEC. 16053, 867638.
14	842541	1	Link rod	D42A PP SPEC. 16053, 867638.
15	955844	1	Nut	D42A PP SPEC. 16053, 867638.
16	941905	1	Spring washer	D42A PP SPEC. 16053, 867638.
17	664822	1	Lock spring	(678146). D42A PP SPEC. 16053, 867638.
18	76614	2	Rubber collar	D42A PP SPEC. 16053, 867638.
19	955272	1	Screw	D42A PP SPEC. 16053, 867638.
20	941906	1	Spring washer	D42A PP SPEC. 16053, 867638.