



4120

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	837046	1	Injection pump		
2	240909	1	· Governor		
3	240072	1		02C-0700	REPL BY 243083
4		1	· HOUSING	02C-1000	
5	239982	6	· Tappet		
6	240779	6	· · Bolt		
7	240780	6	· · Bushing		
8	240781	6	· · Roller		
9	238379	6	· · Plate		
10	239986	6	· Spring disc		
11	244085	6	· Adjusting plate		(239985)
12	239984	6	· Spring disc		
13	240782	6	· Control sleeve		
14	239991	6	· Cover		
15	241677	6	· Washer		
15A	239990	6	· Lock ring		
16	240003	6	· Spacer ring		
17	240002	6	· O-ring		
18	240424	X	· Gasket		TH = 0.15 MM
	240004	X	· Gasket		TH = 0.40 MM
	240005	X	· Gasket		TH = 0.50 MM
	240006	X	· Gasket		TH = 0.60 MM
	240007	X	· Gasket		TH = 0.70 MM
	240008	X	· Gasket		TH = 0.80 MM
19	243741	6	· Bushing		REPAIR KIT 6211269
21	240422	12	· O-ring		
22	239988	6	· Pump element		
23	240783	6	· Delivery valve		
24	239993	6	· Gasket		
25	243771	6	· Delivery valve retai		
26	243743	12	· Washer		REPAIR KIT 6211269
27	238309	6	· Spring		
29	240001	6	· Gasket		
30	240010	12	· Screw		
31	941908	12	· Spring washer		
32	955783	12	· Nut		
33	240011	1	· Cover		
34	956209	2	· Screw		
35	18891	2	· Lock washer		
36	240425	1	· Control rod		
37	240014	2	· Guide sleeve		
38	244008	1	· Lock pin		(131015)
39	240015	1	· Bushing		
41	240971	6	· Plug		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
42	238312	X	· Adjusting washer		TH = 0.3 MM
	241734	X	· Adjusting washer		TH = 0.5 MM
	238314	X	· Adjusting washer		TH = 1.0 MM
43	837735	6	· Plug		
43A	18836	6	· Gasket		
44	243263	1	· Plug		
46	240017	1	· Gasket		
47	240789	1	· Camshaft		
48	240426	1	· Bearing		
49	240427	2	· Screw		
50	941906	2	· Spring washer		
51	240023	1	· Roller bearing		
52	240022	1	· Sealing ring		
53	243299	1	· O-ring		
54	240024	X	· Adjusting washer		TH = 0.10 MM
	240025	X	· Adjusting washer		TH = 0.12 MM
	240026	X	· Adjusting washer		TH = 0.14 MM
	240027	X	· Adjusting washer		TH = 0.16 MM
	240028	X	· Adjusting washer		TH = 0.18 MM
	240029	X	· Adjusting washer		TH = 0.30 MM
	240030	X	· Adjusting washer		TH = 0.50 MM
55	240021	1	· Cover		
56	956094	4	· Screw		
57	941906	4	· Spring washer		
58	955806	1	· Nut		
59	941913	1	· Spring washer		
60	35168	1	· Key		
61	240023	1	· Roller bearing		
62	240032	1	· Ring		
63	240033	X	· Adjusting washer		TH = 1.2 MM
	240034	X	· Adjusting washer		TH = 1.5 MM
	240035	X	· Adjusting washer		TH = 1.8 MM
	240036	X	· Adjusting washer		TH = 2.0 MM
64	240947	1	· Cover		
65	240948	1	· Gasket		
66	956205	12	· Screw		
67	239896	1	· Gasket		
68	130673	3	· Stud		
69	955781	3	· Nut		
70	941906	3	· Spring washer		
72	241647	1	· Setting indicator		
73	100101	2	· Screw		
74	941906	2	· Spring washer		