



5426

**THERMOSTAT AND WATER PUMP WITH INSTALLATION COMPONENTS:  
D120A**

**02B**

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	822330	1	Water pump		
	3803206	1	Circ. pump, exch		Exchange unit
2	823484	1	· Shaft	IK	
3	421306	1	· Wear ring	IK	
4	1542833	1	· Sealing ring	IK	
5	70913	1	· Deflector	IK	
6	181670	1	· Ball bearing	IK	
7	11013	1	· Ball bearing	IK	
8	181538	1	· Ball bearing	IK	
9	422202	1	· Spacer sleeve		
10	914462	1	· Lock ring	IK	
11	423125	1	· Pulley		
12	422499	1	· Pulley		REPLACED BY 1EA 1544097.
13	955525	4	· Screw		REPLACED BY 1EA 1544097.
14	941907	4	· Spring washer		
15	951969	1	· Pin	IK	
16	952077	2	Plug		
17	423351	1	Gasket	IK	
18	955536	5	Screw		
19	955542	2	Screw		
20	942336	7	Spring washer		
21	951973	2	Grooved pin		
22	836788	1	Thermostat housing		
23	423352	1	Gasket	IK	
24	416033	3	Sealing ring	IK	
25	1544297	3	Thermostat		76%Z9 (824200)
26	822344	1	Cover		
27	952077	4	Plug		
28	180761	3	Plug		
29	11996	3	Gasket	IK	
30	959796	2	Screw		L = 140 MM
	959798	2	Screw		L = 152 MM. REPLACED BY 1EA 1544389.
31	959798	4	Screw		
	959796	4	Screw		WATER PUMP SHAFT LENGHT=203 MM.
32	940097	6	Washer		
33	822430	1		02B-0300	REPL BY 423137
34	423138	1	Gasket	IK	
35	955540	2	Screw		
36	942336	2	Spring washer		
37	82745	1	Tap		EARLY TYPE
38	952075	1	Plug		LATE TYPE
39	941845	1	Nipple		
40		1	BELT TRANSMISSION	02B-0200	
42	468552	1	Water pipe		
43	467366	3	· Plug		
44	468463	3	· Gasket	IK	
45	423281	6	Sealing ring	IK	
46	955525	12	Screw		
47	941907	12	Spring washer		
48	470464	1	Hose		(468216)
49	943480	2	Clamp		(951797)
	875461	1	Repair kit		SEE GROUP 10A