



5065

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	241699	1	Injection pump		REPL BY 836910
	836910	1	Injection pump	02C-0300	MO3926/XXXXX-
				02C-0250	
2	468558	1	Bracket		
3	423161	2	Guide sleeve		
4	417588	1	Guide sleeve		
5	955566	4	Screw		
6	940280	4	Spring washer		
7	940156	4	Screw		
8	190509	4	Washer		
9	466398	1	Pressure equalizer		
10	957178	1	Gasket	IK	
11		1	COUPLING	02C-0200	
12		1	WATER SEPARATOR	02C-0850	
13	241672	1	Filter housing		INCLUDED IN FUEL INJECTOR.
				02C-0750	
14	960630	2	Plug		
15	957178	2	Gasket	IK	
16	823264	1	BRACKET		INCLUDED IN FUEL INJECTION PUMP. SEE GROUP 2B
17	955537	2	Screw		INCLUDED IN FUEL INJECTION PUMP.
	940162	2	Screw		
18	955827	2	Nut		INCLUDED IN FUEL INJECTION PUMP.
19	940097	4	Washer		INCLUDED IN FUEL INJECTION PUMP.
20	942336	2	Spring washer		
21	35096	1	Overflow valve		
22	957178	1	Gasket	IK	
23	468217	6	Injector		
				02C-0650	
24	941928	12	Stud		
25	417110	12	Nut		
26	823522	1	Tube		INCLUDED IN FUEL INJECTION PUMP.
	836781	1	Tube		
27	823523	1	Tube		INCLUDED IN FUEL INJECTION PUMP.
	836782	1	Tube		
28	25167	5	Hollow screw		
29	957178	12	Gasket	IK	
30	404279	4	Clamp		
31	950047	2	Screw		
32	955825	2	Nut		
33	16496	1	Hollow screw		
34	423344	1	Tube		
35	423345	1	Tube		
36	423346	1	Tube		
37	423347	1	Tube		
38	423348	1	Tube		
39	423349	1	Tube		
40	414346	4	Clamp		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
41	414347	4	Rubber spacer		
42	414344	6	Clamp		
43	414345	6	Rubber spacer		
44	955247	8	Screw		
45	414736	1	Nut plate		
46	468005	2	Bracket		
47	940100	3	Screw		
48	941906	3	Spring washer		
49	822564	1	Leak-off pipe		MO-XXXXX/1495.
49A	837794	1	Fuel hose		MO-XXXXX/1495.
50	74034	1	Hollow screw		MO-XXXXX/1495.
51	74033	1	Hollow screw		
52	957171	14	Gasket	IK	
52A	957171	1	Gasket	IK	MO-XXXXX/1495.
53	824464	1	Tube		MO-XXXXX/3687
	836783	1	Tube		MOXXXXX/3688
54	842656	1	Fuel pipe		
55	942542	1	Clamp		
56	821036	1	Clamp		
57	952625	1	Clamp		
58	950046	1	Screw		
59	955825	1	Nut		
60	941906	1	Spring washer		
61	821625	1	Anchorage		
62	941492	1	Clamp		
63	950046	1	Screw		
64	955825	1	Nut		
65	941906	1	Spring washer		
66	423393	1	Pressure oil line		
67	48634	1	Hollow screw		
68	942081	1	Hollow screw		
69	957173	2	Gasket	IK	
70	18666	1	Gasket	IK	
71	11994	1	Gasket	IK	
72	422246	1	Pipe		
73	25167	1	Hollow screw		
74	954394	1	Hollow screw		
75	957178	3	Gasket	IK	
76	957181	1	Gasket	IK	
77	239056	1	Spring		FOR GENERATING UNIT.
78	239059	1	Cover		FOR GENERATING UNIT.
79	821134	1	Lever		
80	120265	1	Washer		
81	955637	1	Screw		
82	941906	1	Spring washer		
83	422400	1	Bracket		
84	955249	2	Screw		
85	414735	2	Nut plate		
86	468210	6	Sealing ring		SEE GROUP 2A
87	845450	2	Fuel hose		(880618)
88	956983	4	• Nut		
89	956969	4	• Ferrule		