



7237

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	6212666	1	Centrifugal governor		
2		1	· HOUSING		
2A		1	· · HOUSING		
3	244578	1	· · Bushing		
4	244587	1	· · Shaft		
5	244588	1	· · Lever		
6	241102	1	· · Screw		
7	244590	1	· · Spacer ring		
8	244589	1	· · Spring		
9	239908	1	· · Gasket		
10	955894	1	· · Washer		(906825)
11	233372	1	· · Washer		
12	951669	1	· · Retaining ring		
13	77582	1	· · Key		
14	6212459	2	· Screw		
15	6212633	2	· Screw		
16	6210701	4	· Screw		
17	244552	4	· Retainer		
18	240688	2	· Plug		
19	1698169	2	· Gasket		
20	6211236	1	· Gasket	02C-0200	
21	6212645	1	· Cover		
22	233423	1	· · Shaft		
23	240691	1	· · Bushing		
24	241989	2	· · Sealing ring		
25	910112	1	· · Key		
26	239316	1	· · Lever		
27	955272	1	· · · Screw		
28	6212646	1	· · Screw		
29	955781	1	· · Nut		
30	238127	1	· · Angle piece		
31	233071	X	· · Plate		TH=0.20 MM
	233072	X	· · Plate		TH=0.30 MM
	240568	X	· · Plate		TH=0.50 MM
	233427	X	· · Plate		TH=0.80 MM
32	244625	1	· · Striker plate		
33	955273	1	· · Screw		
34	941906	1	· · Spring washer		
35	233104	2	· · Pin		
36	244666	1	· · Link arm		
37	238128	2	· · Washer		
38	233103	2	· · Pin		
39	244632	2	· · Stud		
40	239324	1	· Control rod		
41	907819	2	· Cotter pin		
42	240696	1	· Bushing		
43	955780	1	· Nut		
44	240704	2	· Sleeve		
45	243295	1	· Gasket		
46	243296	1	· Gasket		
47		1	· COVER		
48	941906	2	· Spring washer		
49	956091	1	· Screw		
50	6210714	1	· Hollow screw		
51	240695	1	· Cold start		
52		1	· · HOUSING		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
53	240697	1	• • Bolt		
54	240698	1	• • Washer		
55	120279	X	• • Adjusting washer		TH=0.2 MM
	233609	X	• • Adjusting washer		TH=0.3 MM
	120278	X	• • Adjusting washer		TH=0.5 MM
	240699	X	• • Adjusting washer		TH=1.0 MM
56	941905	1	• • Spring washer		(241136)
57	240700	1	• • Bolt		
58	240701	1	• • Spring		
59	240703	1	• • Gasket		
60	240702	1	• • Actuator solenoid		
61	241138	2	• • Screw		
62	941905	2	• • Spring washer		(955918)
63	239927	1	• Guide screw		
64	240683	1	• Arm		
65	240682	1	• Link section		
66	240861	1	• Bearing bolt		
67	239914	1	• Fork		
68	244546	1	• Connection plate		
69	243447	1	• Screw		
70	907824	1	• Cotter pin		
71	845428	2	• Rivet		
72	244547	1	• Spring		
73	244556	1	• Bolt		
74	244557	1	• Bushing		
75	244555	1	• Plug		
76	238959	1	• Washer		
77	240856	1	• Hub		
78	244980	1	• • Companion flange		(241122)
79	233130	4	• • Rubber damper		
80	240678	1	• • Nut		
81	238106	X	• • Adjusting washer		TH=1.60 MM
	244755	X	• • Adjusting washer		(238105) TH=1.65 MM
	244756	X	• • Adjusting washer		(233090) TH=1.70 MM
	244758	X	• • Adjusting washer		(233415) TH=1.75 MM
	244760	X	• • Adjusting washer		(233089) TH=1.80 MM
	244761	X	• • Adjusting washer		(233414) TH=1.85 MM
	233088	X	• • Adjusting washer		TH=1.90 MM
	233413	X	• • Adjusting washer		TH=1.95 MM
	244766	X	• • Adjusting washer		(233087) TH=2.00 MM
	240563	X	• • Washer		TH=2.05 MM
	240564	X	• • Washer		TH=2.10 MM
82	241123	1	• • Cardboard tube		
83	233052	1	• • Screw kit		
84	240051	1	• Bushing		
85	240565	2	• Striker plate		
86	955270	2	• Screw		
87	6211256	2	• Spring		
88	240857	2	• Spring disc		
89	6211255	2	• Spring		
90	244414	2	• Spring		
91	244622	2	• Spring disc		
92	244623	2	• Nut		
93	239889	1	• Gasket		
94	241990	5	• Screw		
95	244553	1	• Screw		
96	956097	1	• Screw		
97	243844	1	• Nut		