



2204

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	254595	1			
2	346622	1			
3	334186	1	· Plug		
4	190300	3	· Plug		
5	344188	2			
6	180764	2	· Plug		
7	337336	1			
8	15311	1	· Sealing ring		
10	346625	1	· Cover		
11	346626	1			
12	334204	X	· Spacer		TH = 0.2 MM
	334205	X	· Spacer		TH = 0.3 MM
13	334234	8	· Stud		
14	190296	8	· Lock washer		
15	955782	8	· Nut		
16	346679	1	· Cover		
17	6770964	1	· Sealing ring		(346682)
18	346680	1	· Gasket		
19	339735	X	· Adjusting washer		TH = 0.2 MM
	339734	X	· Adjusting washer		TH = 0.3 MM
20	17394	3	· Stud		L = 15 MM
	334206	4	· Stud		L = 22 MM
	352746	2			L = 35 MM
21	190819	9			
22	955782	9	· Nut		
23		1	· INPUT SHAFT	04E-0150	
24		1	· COUNTER SHAFT	04E-0250	
25		1	· MAIN SHAFT	04E-0150	
26		1	· REVERSE SHAFT	04E-0250	
27	346648	1	· Speedometer gear		
28	346649	1	· Companion flange		
29	191510	1	· Nut		
30	951982	1	· Spring pin		
31	348829	1	· Cover		
32	350185	1	· Gasket		
33	955343	4	· Screw		
34	940280	4	· Spring washer		
35		1	· GEAR BOX COVER	04E-0300	
36	346656	1	· Gasket		
37	334232	10	· Screw		L = 22 MM
38	955303	2	· Screw		L = 65 MM
39	190819	12			
40	346671	1	· Cover		
41	190300	1	· Plug		
42	346672	1	· Shift lever		
43	346673	2	· Seat		
44	346674	X	· Washer		
45	914523	1	· Lock ring		
46	346675	1			
47	321262	1			
48	321263	1			
49	346676	1	· Bellows		
50	191124	1	· Washer		
51	955784	1	· Nut		
52	346677	1	· Gasket		
53	326657	2			
54	346678	8	· Stud		
55	190819	10			
56	955782	8	· Nut		