



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	GENERATOR AND CHARGING RELAY WITH INSTALLATION COMPONENTS	030-0900	SPEC.867066
2	827348	1	Alternator		14V 38A REPL BY 847604
	847604	1	Alternator, ALTERNATOR	030-0850	14V 35A
	827349	1	Alternator	030-0875	28V 25A REPL BY 847561
	847561	1	Alternator, ALTERNATOR	030-0850	28V 30A
		1	ALTERNATOR AND INSTALLATION COMPONENTS, MOXXXXX/33072-	030-0875 030-0575	
		1	ALTERNATOR 1578140 AND INSTALLATION COMPONENTS	030-0600	ALT
3	843248	1	Pulley		STD
4	947950	1	V-belt		
5	820895	1	Bracket		STD
6	955555	1	Screw		
7	950355	1	Nut		
8	825626	1	Tensioner		
9	940161	1	Screw		(940186)
10	191172	1	Washer		
11	950353	1	Lock nut		
12	955525	1	Screw		
13	950353	1	Lock nut		
14	240501	1			12V REPL BY 843511. EARLY TYPE.
	842775	1		030-1150	12V REPL BY 843511. EARLY TYPE.
	843511	1	Starter motor	030-1150	12V REPL BY 847306. LATE TYPE.
	847306	1	Starter motor	030-1250	12V
	241965	1		030-1255	24V REPL BY 843510. EARLY TYPE.
	842774	1	Starter motor		24V REPL BY 843510. EARLY TYPE.
	843510	1	Starter motor	030-1150	24V. D70B,TD70B MO-86645/XXXXX.D70B SPEC.867283.CLASSIFIED ENGINE. LATE TYPE.. REPLACED BY 1EA 847307 STARTER.
	847307	1	Starter motor	030-1250	24V
	842551	1		030-1260	24V REPL BY 466772. D70B, TD70B MO 86646/XXXXX- EXCL SPEC 867283.
				030-1225	

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
14	466772	1	Starter motor		24V, REPL BY 465604
				030-1201	
	465604	1	Starter motor		24V
	3803068	1	Starter motor, exch		Exchange unit
		X	· COMPONENTS NOT SPEC.		
	4774617	1	Starter motor		24V. OIL PROTECTED STARTER.
				030-1250	
	823412	1	Starter motor		COMPONENTS NOT STOCKED AS SPARE.
15		1	SPACER		
16	953486	3	Stud		
17	942336	3	Spring washer		
18	955827	3	Nut		
19	11411	1	Ground cable		
20	837582	1	Push button		SPEC 867065, 867066.
21	821389	1	Sign		SPEC 867065, 867066.
22	821388	1	Sign		SPEC 867065, 867066.
23	821681	1			SPEC 867065, 867066.
24	940133	2	Screw		SPEC 867065, 867066.
25	940097	2	Washer		SPEC 867065, 867066.
26		1	CONNECTING BOX	030-0401	
27		1	DRIVE DEVICE		SEE GROUP 2C
28		1	INSTRUMENT PANEL AND INSTALLATION COMPONENTS	030-1450	
29	820553	1			1200R/M. MECHANICAL.
	820554	1	Hour counter		1500R/M. MECHANICAL.
	820555	1	Hour counter		1800R/M. MECHANICAL.
	820556	1	Hour counter		2000R/M. MECHANICAL.
30	325842	1	Nut		
31	843812	1	Switch		
32	942490	1	T-nipple		
33	881432	1	Pressure sensor		D70B SPEC 867054-867059, 867132, 867259, 867260, 867276- 867279, 867300, 867301. CLASSIFIED SPEC 867053. TD70B SPEC 867281.
34	1507899	1	Tachometer sensor		
35	880778	1	Thermo monitor		D70B SPEC.867055-ENGINE WITH"FENWAL"THERMOSWITCH CONTROL -EARLY TYPE.. D70B SPEC 867054. TD70B SPEC 867065 ALT.EARLY TYPE . CLASSIFIED SPEC 867053.
36	898739	1	Protecting sleeve		D70B SPEC.867055-ENGINE WITH"FENWAL"THERMOSWITCH CONTROL -EARLY TYPE.. D70B SPEC 867054. TD70B SPEC 867065 ALT.EARLY TYPE . CLASSIFIED SPEC 867053.
37	898740	1	Cover		D70B SPEC.867055-ENGINE WITH"FENWAL"THERMOSWITCH CONTROL -EARLY TYPE.. D70B SPEC 867054. TD70B SPEC 867065 ALT.EARLY TYPE . CLASSIFIED SPEC 867053.
38	925057	1	Rubber ring		D70B SPEC.867055-ENGINE WITH"FENWAL"THERMOSWITCH CONTROL -EARLY TYPE.. D70B SPEC 867054. TD70B SPEC 867065 ALT.EARLY TYPE . CLASSIFIED SPEC 867053.
39	822858	1	Thermo monitor		93%Z9C. D70B SPEC 867055.LATE TYPE.. D70B SPEC. 867054,867259,867260,867277,867278, 867300 867301. TD70B SPEC 867065. ALT.LATE TYPE.
41	827150	1	Temperature sensor		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
42	16212	1	Nipple		
43	850420	1	Horn		
44	955827	1	Nut		
45	955535	1	Screw		
46	942336	1	Spring washer		
47	823572	1	Cable kit		D70B SPEC.867060.TD70B SPEC.867066 BOSCH GENERATOR.
		X	· CABLES AND TERMINALS	030-1550	
	836193	1	Cable trunk		D70B SPEC 867055.LATE TYPE.. D70B SPEC 867054, 867056, 867060, 867063, 867132, 867259, 867260, 867276, 867278, 867280, 867281, 867282, 867300, 867301. TD70B.
		X	· CABLES AND TERMINALS	030-1550	
	837269	1			LARM DEVICE-SPECIAL PRODUCTION FOR" HYMAC".
		X	· CABLES AND TERMINALS	030-1550	
48	948210	X	Strip clamp	030-1550	
49		1	CABLE HOLDER		
50	940135	1	Screw		
51	941907	1	Spring washer		
52		1	CHARGING RELAY AND INSTALLATION COMPONENTS	030-0250	
62		1	STARTING ELEMENT AND INSTALLATION COMPONENTS	030-1300	