



11838

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	384249	1		RATIO 4,87:1
2	384039	1		
3		2	• • CAP	
4	104109	4	• • Screw	
5	120173	4	• • Washer	
6	310719	4	• • Bushing	
7	952075	1	• Plug	
8	384016	1		
9	191394	12	• Screw	
10	191055	12	• Castle nut	
11	907849	12	• Cotter pin	
12	311760	1	• Spider	
13		4	• DIFFERENTIAL WHEEL	REPL BY 273431
14	120226	4	• Thrust washer	
15		2	• DIFFERENTIAL WHEEL	REPL BY 273431
16	120228	2	• Thrust washer	
17	384036	1	• Housing	LEFT
18	384037	1		RIGHT EARLY PROD
19	192152	12	• Screw	
20	153003	12	• Nut	
21	907849	12	• Cotter pin	
22	184113	1	• Roller bearing	
23	384045	1	• Sleeve	
24		1	• • OUTER RING	ERS AV 184634
25	384477	1	• • Oil plate	
26		1	• • OUTER RING	ERS AV 184633
27		1	• ROLLER BEARING, CONE	ERS AV 184634
28	384612	X	• Spacer sleeve	TJ=5.54 MM
	384613	X	• Spacer sleeve	TJ=5.56 MM
	384614	X	• Spacer sleeve	TJ=5.62 MM
	384615	X	• Spacer sleeve	TJ=5.68 MM
	384616	X	• Spacer sleeve	TJ=5.74 MM
	384617	X	• Spacer sleeve	TJ=5.76 MM
29		1	• ROLLER BEARING, CONE	ERS AV 184633
30	1522895	1	• Seal	
31	943142	1	• Sealing ring	
32	384068	X	• Adjusting washer	TJ=0.10 MM
	384070	X	• Adjusting washer	TJ=0.35 MM
	384072	X	• Adjusting washer	TJ=1.00 MM
33	955577	6	• Screw	
34	941911	6	• Spring washer	
35		1	• COMPANION FLANGE	REPLACED BY 1EA 382990, 1EA 943805, 1EA 914480.
36	382015	1	• • Dust cover	
37	943805	1	• Nut	
38	941700	1	• Washer	
39	183704	2	• Roller bearing, COMPL.	
39A	181298	2	• • Roller bearing	ERS AV 183704
40	181128	2	• • Cup	ERS AV 183704
41	384044	2	• Adjusting device	
42	307451	2	• Lock	
43	955523	4	• Screw	
44	955949	4	• Lock washer	