



| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|---|----------|--------------------|
| 1 | | 1 | STARTER MOTOR | 030-1045 | |
| 2 | | 1 | ALTERNATOR AND INSTALLATION COMPONENTS, LOW RIGHT | 030-0740 | |
| | | | | | * |
| 2 | | 1 | ALTERNATOR AND INSTALLATION COMPONENTS, LOW LEFT | 030-0720 | |
| | | | | | * |
| | | 1 | ALTERNATOR AND INSTALLATION COMPONENTS, LOW LEFT | 030-0693 | ALT.45A |
| | | | | | * |
| | | 1 | ALTERNATOR AND INSTALLATION COMPONENTS HIGH RIGHT | 030-0760 | |
| | | | | | * |
| 3 | | 1 | STARTER RELAY AND INSTALLATION COMPONENTS | 030-1225 | |
| | | | | | * |
| 4 | | 1 | STOP SOLENOID INSTALLATION COMPONENTS | | SEE GROUP 2D |
| 5 | 3013297 | 1 | Tachometer sensor | | |
| 6 | 863604 | 1 | Gasket | | |
| 7 | 862154 | 1 | Temperature sensor | | |
| 8 | 848829 | 1 | Temperature sensor | | 103%Z9C,STD |
| | 862250 | 1 | Thermo monitor | | 97%Z9C,ALT |
| 9 | 947624 | 2 | Gasket | | |
| 10 | 835980 | 1 | Nipple | | |
| 11 | 862155 | 1 | Sender | | |
| 12 | 863197 | 1 | | | |
| 13 | | 1 | STARTING HEATER AND INSTALLATION COMPONENTS | | |
| | | | | | SEE GROUP 2B |
| 14 | | 1 | INSTRUMENT BOX | 030-1470 | |
| 15 | 862260 | 1 | Cable trunk | | CABLE UNIT ENGINE. |
| 16 | 863227 | 1 | Adapter | | EARLY TYPE |
| 17 | | X | CABLES AND TERMINALS | 030-1500 | |
| 18 | | X | EXTRA EL.EQUIPMENT | 030-1490 | |