



9983

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	STARTER MOTOR	030-1045	
2		1	ALTERNATOR AND INSTALLATION COMPONENTS, LOW LEFT	030-0720	
					*
3		1	STARTER RELAY AND INSTALLATION COMPONENTS	030-1215	
					*
4		1	STOP SOLENOID AND INSTALLATION COMPONENTS		SEE GROUP 2D
5	3013297	1	Tachometer sensor		
6	863604	1	Gasket		
7	862154	1	Temperature sensor		
8	848829	1	Temperature sensor		103%Z9C
9	947624	2	Gasket		
10	835980	1	Nipple		
11	862155	1	Sender		
12	863169	1	Pressure monitor		(864284)
13		1	STARTING HEATER AND INSTALLATION COMPONENTS		SEE GROUP 2B
14		1	INSTRUMENT BOX	030-1470	
15	862260	1	Cable trunk		CABLE UNIT ENGINE.
16	863227	1	Adapter		EARLY TYPE
17		X	CABLES AND TERMINALS	030-1500	
18		X	EXTRA EL.EQUIPMENT	030-1490	