



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	842738	1	Injection pump		
				02C-0150	
2	468558	1	Bracket		
3	423161	2	Guide sleeve		
4	417588	1	Guide sleeve		
5	955566	4	Screw		
6	940280	4	Spring washer		
7	940156	4	Screw		
8	190509	4	Washer		
9	466398	1	Pressure equalizer		
10	18671	1	Gasket	IK	
11		1	COUPLING	02C-0100	
12	821134	1	Lever		
13	239056	1	Spring		
14	239059	1	Cover		
15	120265	1	Washer		
16	955637	1	Screw		
17	941906	1	Spring washer		
18	241672	1	Filter housing		INCLUDED IN FUEL INJECTOR.
				02C-0350	
19	844024	1	Bracket		
20	960630	3	Plug		
21	18671	3	Gasket	IK	
22	940114	2	Screw		
23	960142	2	Washer		
24	942336	2	Spring washer		
25	955827	2	Nut		
26	940162	1	Screw		L = 38 MM
	955536	1	Screw		L = 45 MM
27	942336	2	Spring washer		
28	468480	1	Fuel pipe		
29	468481	1	Fuel pipe		
30	25167	4	Hollow screw		
31	18671	8	Gasket	IK	
32	404279	2	Clamp		
33	950047	1	Screw		
34	955825	1	Nut		
35	423393	1	Pressure oil line		
36	48634	1	Hollow screw		
37	957173	2	Gasket	IK	
38	942081	1	Hollow screw		
39	11994	1	Gasket	IK	
40	18666	1	Gasket	IK	
41	842656	1	Fuel pipe		
42	25167	1	Hollow screw		
43	18671	2	Gasket	IK	
44	422246	1	Pipe		
45	25167	1	Hollow screw		
46	18671	3	Gasket	IK	
47	954394	1	Hollow screw		
48	11998	1	Gasket	IK	
49	842657	1	Fuel pipe		
50	821625	1	Anchorage		
51	404279	1	Clamp		
52	950048	1	Screw		
53	955893	1	Washer		
54	955825	1	Nut		
55	404279	2	Clamp		
56	950047	1	Screw		
57	955825	1	Nut		
58	845326	1	Leak-off pipe		(844893)
59	35096	1	Overflow valve		
60	18671	1	Gasket	IK	(15304)
61	18671	2	Gasket	IK	

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
62	16496	1	Hollow screw		
63	74033	1	Hollow screw		
64	946729	2	Gasket	IK	
65	468627	6	Injector		
				02C-0300	
66	468210	6	Sealing ring	IK	
67	944189	12	Stud		
68	417110	12	Nut		
69	822564	1	Leak-off pipe		
70	74034	1	Hollow screw		
71	947620	3	Gasket	IK	
72	74033	5	Hollow screw		INCLUDED IN REPAIR KIT 6210762.
73	946729	10	Gasket	IK	INCLUDED IN REPAIR KIT 6210762.
74	121563	1	Clamp		
75	950045	1	Screw		
76	941906	1	Spring washer		
77	468600	1	Delivery pipe		
78	468601	1	Delivery pipe		
79	468602	1	Delivery pipe		
80	423515	1	Delivery pipe		
81	423516	1	Delivery pipe		
82	423517	1	Delivery pipe		
83	414345	8	Rubber spacer		
84	414344	8	Clamp		
85	414736	1	Nut plate		
86	468005	3	Bracket		
87	940100	3	Screw		
88	941906	3	Spring washer		
89	414347	4	Rubber spacer		
90	414346	4	Clamp		
91	414735	2	Nut plate		
92	955249	12	Screw		
93	845450	2	Fuel hose		(880618)
94	956983	4	• Nut		
95	956969	4	• Ferrule		