



| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|------------------------|----------|--------------|
| 1 | 846929 | 1 | Injection pump | | |
| 2 | 845214 | 1 | · Centrifugal governor | | |
| | | | | 02C-0935 | |
| 3 | 244391 | 1 | · Feed pump | | |
| | | | | 02C-1200 | |
| 4 | | 1 | · PUMP HOUSING | | |
| 5 | 244404 | 6 | · Push rod | | |
| 6 | 240779 | 6 | · · Bolt | | (846578) |
| 7 | 240780 | 6 | · · Bushing | | |
| 8 | 846577 | 6 | · · Bearing | | |
| 9 | 238739 | 6 | | | |
| 10 | 847277 | 6 | · Spring | | |
| 11 | 244402 | 6 | · Compression spring | | |
| 12 | 239984 | 6 | · Spring disc | | |
| 13 | 240782 | 6 | · Control sleeve | | |
| 14 | 239991 | 6 | · Cover | | |
| 15 | 844988 | 1 | · Plug | | |
| 16 | 239990 | 6 | · Lock ring | | (243668) |
| 17 | 241677 | 6 | · Washer | | |
| 18 | 846937 | 6 | · O-ring | | |
| 19 | 844990 | X | · Adjusting washer | | TH = 0.4 MM |
| | 844991 | X | · Adjusting washer | | TH = 0.50 MM |
| | 844992 | X | · Adjusting washer | | TH = 0.70 MM |
| | 844993 | X | · Adjusting washer | | TH = 0.80 MM |
| | 844994 | X | · Adjusting washer | | TH = 1.00 MM |
| | 844995 | X | · Adjusting washer | | TH = 1.10 MM |
| | 244633 | X | · Adjusting washer | | TH = 1.20 MM |
| | 844996 | X | · Adjusting washer | | TH = 1.25 MM |
| | 244634 | X | · Adjusting washer | | TH = 1.30 MM |
| | 244635 | X | · Adjusting washer | | TH = 1.40 MM |
| | 244381 | X | · Adjusting washer | | TH = 1.50 MM |
| | 244382 | X | · Adjusting washer | | TH = 1.60 MM |
| | 244383 | X | · Adjusting washer | | TH = 1.70 MM |
| | 244384 | X | · Adjusting washer | | TH = 1.80 MM |
| | 244385 | X | · Adjusting washer | | TH = 1.90 MM |
| | 244386 | X | · Adjusting washer | | TH = 2.00 MM |
| 20 | 244407 | 6 | · Bushing | | |
| 21 | 18836 | 6 | · Gasket | | |
| 22 | 240422 | 12 | · O-ring | | |
| 23 | 846576 | 6 | · Pump element | | |
| 24 | 846188 | 6 | · Delivery valve | | |
| 25 | 239993 | 6 | · Gasket | | |
| 26 | 240969 | 6 | · Spring | | |
| 27 | 240001 | 6 | · Gasket | | |
| 28 | 244636 | 6 | · Delivery valve retai | | |
| 29 | 243743 | 12 | · Washer | | |
| 30 | 244380 | 12 | · Stud | | |
| 31 | 941908 | 12 | · Spring washer | | |
| 32 | 943927 | 12 | · Nut | | |
| 33 | 240011 | 1 | · Cover | | |
| 34 | 956209 | 2 | · Screw | | |
| 35 | 18891 | 2 | · Lock washer | | |
| 36 | 240907 | 1 | · Control rod | | |
| 37 | 240014 | 2 | · Guide sleeve | | |
| 38 | 244008 | 1 | · Lock pin | | |
| 39 | 846938 | 1 | · Bushing | | |
| 40 | 6642955 | 1 | · Screw | | |
| 41 | 947620 | 1 | · Gasket | | |
| 42 | 130673 | 3 | · Stud | | |
| 43 | 240971 | 6 | · Plug | | |
| 44 | 240972 | X | · Washer | | TH = 0.2 MM |
| | 240973 | X | · Washer | | TH = 0.5 MM |
| 45 | 180707 | 1 | · Plug | | |
| 46 | 243263 | 1 | · Plug | | |

| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|---------------------|----------|--------------|
| 47 | 240017 | 1 | · Gasket | | |
| 48 | 845454 | 1 | · Camshaft | | |
| 49 | 244406 | 1 | · Bearing | | |
| 50 | 240427 | 2 | · Screw | | |
| 51 | 941906 | 2 | · Spring washer | | |
| 52 | 240023 | 1 | · Roller bearing | | |
| 53 | 240022 | 1 | · Sealing ring | | |
| 54 | 243299 | 1 | · O-ring | | |
| 55 | 240024 | X | · Adjusting washer | | TH = 0.10 MM |
| | 240025 | X | · Adjusting washer | | TH = 0.12 MM |
| | 240026 | X | · Adjusting washer | | TH = 0.14 MM |
| | 240027 | X | · Adjusting washer | | TH = 0.16 MM |
| | 240028 | X | · Adjusting washer | | TH = 0.18 MM |
| | 240029 | X | · Adjusting washer | | TH = 0.30 MM |
| | 240030 | X | · Adjusting washer | | TH = 0.50 MM |
| 56 | 240021 | 1 | · Cover | | |
| 57 | 956094 | 4 | · Screw | | (243714) |
| 58 | 941906 | 4 | · Spring washer | | |
| 59 | 955806 | 1 | · Nut | | |
| 60 | 955927 | 1 | · Spring washer | | |
| 61 | 35168 | 1 | · Key | | |
| 62 | 240023 | 1 | · Roller bearing | | |
| 63 | 240032 | 1 | · Ring | | |
| 64 | 240033 | X | · Adjusting washer | | TH = 1.2 MM |
| | 240034 | X | · Adjusting washer | | TH = 1.5 MM |
| | 240035 | X | · Adjusting washer | | TH = 1.8 MM |
| | 240036 | X | · Adjusting washer | | TH = 2.0 MM |
| 65 | 240947 | 1 | · Cover | | |
| 66 | 240948 | 1 | · Gasket | | |
| 67 | 956205 | 12 | · Screw | | |
| 68 | 6212117 | 1 | · Plate | | |
| 69 | 940197 | 3 | · Nut | | |
| 70 | 941906 | 3 | · Spring washer | | |
| 71 | 240811 | 1 | · Sealing ring | | |
| 72 | 240812 | 1 | · Cover | | |
| 73 | 240037 | 1 | · Gasket | | |
| 74 | 6638096 | 4 | · Screw | | |
| 75 | 240121 | 1 | · Plug | | |
| 76 | 240016 | 1 | · Protecting casing | | |
| 77 | 240017 | 1 | · Gasket | | |