



10376

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	864528	1	Governor	
2	863535	1		
3	240059	2	• Bushing	
4	233404	1	Shaft	
5	240060	1	Lever	
6	241102	1	Screw	
7	239908	2	Gasket	
8	6212642	2	Washer	
9	233372	X	Washer	
10	244979	2	Lock pin	
11	77582	1	Key	
12	238721	1		
13	955246	1	Screw	
14	849468	2	• Screw	
15	862427	4	• Washer	
16	862428	5	• Screw	
17	863506	2		
18	847909	2	• Regulator spring	(849829)
19	847533	2	• Regulator spring	(849828)
20	848304	2	• Regulator spring	
21	244622	2	• Spring disc	
22	244623	2	• Nut	
23	244745	2	• Washer	
24	239300	8	• Adjusting washer	
25	863536	1		
26	1698514	1		
27	240565	2	• Striker plate	
28	955271	2	• Screw	
29	1698742	2	• Lock spring	
30	238173	1	• Fork	
31	244986	1	• Guide lug	
32	244904	2	• Screw	
33	241705	2	• Washer	
34	244851	1	• Bolt	
35	239927	1	• Guide screw	
36	864529	1		
37	863538	1		
38	862440	2	• • Bushing	
39	863533	1		
40	848305	1	• • Lever	
41	862441	1	• • Shaft	
42	244983	2	• • Pin	
43	910112	1	• • Key	
44	239316	1	• • Lever	
45	1698743	1	• • Screw	
46	241988	1	• • Screw	
47	955781	1	• • Nut	
48	862442	2	• • Seal	
49	238128	2	• • Washer	
50	848306	2	• • Stud	
51	1698167	1	• Gasket	
52	18836	1	• Gasket	
53	863539	1		
54	862808	1	• Nut	
55	863524	1		
56	862448	5	• Screw	
57	240688	2	• Plug	
58	240016	1	• Protecting casing	
59	240017	1	• Gasket	
60	244480	1	• Bearing bolt	
61	863525	1		
62	863526	1		
63	238216	1		
64	863540	1		

REF	PART NO.	QTY	DESCRIPTION	NOTES
65	863528	1		
66		1	• • RING	
67	863530	1		
68	240682	1	• • Link section	
69	240683	1	• • Arm	
70	1698174	1		
71	1698173	1		
72	240864	1	• • Stop, shoulder	
73	863531	1		
74	240865	1		
75	847519	2	• • • Nut	
76	863541	1		
77	963004	1		
78	949607	1	• • • Spring washer	
79	239024	1		
80	244678	1	• • Cover	
81	838340	2	• • Spring ring	
82	830798	1	• • Screw	
83	241779	1	• • Screw	
84	244718	1	• • Washer	
85	244719	1	• • Spring	
86	240704	2	• Sleeve	
87			• SPARE PARTS KIT	
88	1697947	4		
89	1698750	1		
90	1698751	1		
91	244753	X	• • Adjusting washer	TH = 1,60 MM
	244754	X	• • Adjusting washer	TH = 1,63 MM
	244755	X	• • Adjusting washer	TH = 1,66 MM
	244756	X	• • Adjusting washer	TH = 1,69 MM
	244757	X	• • Adjusting washer	TH = 1,72 MM
	244758	X	• • Adjusting washer	TH = 1,75 MM
	244759	X	• • Adjusting washer	TH = 1,78 MM
	244760	X	• • Adjusting washer	TH = 1,81 MM
	244761	X	• • Adjusting washer	TH = 1,84 MM
	244762	X	• • Adjusting washer	TH = 1,87 MM
	244763	X	• • Adjusting washer	TH = 1,90 MM
	244764	X	• • Adjusting washer	TH = 1,93 MM
	244765	X	• • Adjusting washer	TH = 1,96 MM
	244766	X	• • Adjusting washer	TH = 1,99 MM
	244767	X	• • Adjusting washer	TH = 2,02 MM
	244768	X	• • Adjusting washer	TH = 2,05 MM
	244769	X	• • Adjusting washer	TH = 2,06 MM
	244770	X	• • Adjusting washer	TH = 2,11 MM
	244771	X	• • Adjusting washer	TH = 2,14 MM
92	1698752	1		
93	233052	1	• Screw kit	
94	862443	1	• Gasket	