



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	848910	1	Injection pump		
	3803695	1	Injection pump, exch		Exchange unit
				02C-0880	
2	468558	1	Bracket		
3	423161	2	Guide sleeve		
4	417588	1	Guide sleeve		
5	955566	4	Screw		
6	940280	4	Spring washer		
7	940156	4	Screw		
8	190509	4	Washer		
9	477173	1	Pressure equalizer		
10	969011	1	Gasket		
11		1	PUMP COUPLING	02C-0565	
12	848677	1	Lever		
13	239056	1	Spring		NOT FOR ENGINE WITH STOP SOLENOID.
14	239059	1	Cover		NOT FOR ENGINE WITH STOP SOLENOID.
15	120265	1	Washer		
16	955637	1	Screw		
17	941906	1	Spring washer		
18	471172	1	Filter housing		
				02C-1525	
18A	466987	2	Fuel filter		
19	476438	1	Bracket		
20	960630	3	Plug		
21	969011	3	Gasket		
22	940162	1	Screw		L = 38 MM
	955536	1	Screw		L = 45 MM
23	960142	2	Washer		
24	942336	2	Spring washer		
25	955827	2	Nut		
26	940114	2	Screw		
27	942336	2	Spring washer		
28	468480	1	Fuel pipe		
29	468481	1	Fuel pipe		
30	25167	4	Hollow screw		
31	969011	8	Gasket		
32	404279	4	Clamp		
33	950047	2	Screw		
34	955825	2	Nut		
35	862179	1	Tube		(470514)
36	48634	1	Hollow screw		
37	947281	2	Gasket		
38	942081	1	Hollow screw		
39	11994	1	Gasket		
40	18666	1	Gasket		
41	845938	1	Fuel pipe		
42	25167	1	Hollow screw		
43	969011	2	Gasket		
44	422246	1	Pipe		
45	25167	1	Hollow screw		
46	969011	2	Gasket		
46A	11998	1	Gasket		
47	942007	1	Hollow screw		
48	942703	1	Gasket		
49	845937	1	Fuel pipe		
50	821625	1	Anchorage		
50A	470181	5	Clamp		2-PIPE

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
50B	470183	2	Clamp		4-PIPE
50C	422323	1	Bracket		
50D	941906	1	Spring washer		
50E	940100	1	Screw		
51	404279	1	Clamp		
52	950048	1	Screw		
53	955893	1	Washer		
54	955825	1	Nut		
55	404279	2	Clamp		
56	950047	1	Screw		
57	955825	1	Nut		
58	470185	1	Leak-off line		
59	35096	1	Overflow valve		
60	15304	1	Gasket		
61	969011	2	Gasket		
62	16496	1	Hollow screw		
63	848228	6	Injector		
	3803251	6	Injector, exch	02C-1445	Exchange unit
64	469455	6	Sealing ring		
65	469797	6	Yoke		
66	470560	6	Stud		(468749)
67	971095	6	Nut		
68	822564	1	Leak-off pipe		
69	74034	1	Hollow screw		
70	947620	3	Gasket		
71	74033	6	Hollow screw		INCLUDED IN FUEL INJECTOR.
72	946729	12	Gasket		INCLUDED IN FUEL INJECTOR.
73	121563	1	Clamp		
74	950044	1	Screw		
75	941906	1	Spring washer		
76	465584	1	Bracket		
77	940100	1	Screw		
78	941906	1	Spring washer		
79	468981	1	Delivery pipe		
80	468982	1	Delivery pipe		
81	468983	1	Delivery pipe		
82	468984	1	Delivery pipe		
83	862037	1	Delivery pipe		(468985)
84	862038	1	Delivery pipe		(468986)
85	845450	2	Fuel hose		
86	956969	4	Ferrule		
87	956983	4	Nut		