

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	864410	1	Injection pump		
	3803701	1	Injection pump, exch		Exchange unit
				2100	
2	478647	1	Bracket		
3		2	· Guide sleeve		
4	417588	1	· Guide sleeve		
5	955566	4	Screw		
6	940280	4	Spring washer		
7	940156	4	Screw		
8	190509	4	Washer		
9	477173	1	Pressure equalizer		
10	969011	1	Gasket		
11	848677	1	Lever		For stop solenoid.
12	941906	1	Spring washer		For stop solenoid.
13	955637	1	Screw		For stop solenoid.
14	1676832	1	Filter housing		Replaced by 8194541.
	8194541	1	Filter housing		
15	471177	1	· Screw, air venting		FOR 1676832
15A	947620	1	· Gasket		FOR 1676832
16	1330191	1	· Tap		FOR 8194541
16A	656456	1	· Protecting cover		FOR 8194541
17	968062	3	Plug		
18	476438	1	Bracket		
19	3825133	2	Fuel filter		(466987)
20	940162	1	Screw		L=38mm
	955536	1	Screw		L=45mm
21	960142	2	Washer		
22	942336	2	Spring washer		
23	955827	2	Nut		
24	940114	2	Screw		
25	942336	2	Spring washer		
26	470185	1	Leak-off line		
27	969011	X	Gasket		
28	25167	X	Hollow screw		
29	422246	1	Pipe		
30	942007	1	Hollow screw		
31	11998	1	Gasket		
32	942703	1	Gasket		
33	470514	1	Pressure oil line		
34	947281	2	Gasket		
35	48634	1	Hollow screw		
36	942081	1	Hollow screw		
37	11994	1	Gasket		
38	18666	1	Gasket		
39	952631	2	Clamp		
40	967949	1	Screw		(965175)
40A	945407	1	Flange nut		
41	965552	1	Bracket		
42		1	Washerwater pump		
43		1	Screwwater pump		
44	866663	2	Clamp		
45	3826263	1	Fuel hose		
46	3825602	1	Fuel hose		
47	3825603	1	Fuel hose		
48	3826142	1	Fuel hose		
49	25167	1	Hollow screw		
50	969011	2	Gasket		
51	3826145	1	Bracket		
52	823196	2	Spacer sleeve		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
53	843075	2	Sleeve		
54	940280	2	Spring washer		
55	955570	2	Screw		
56	941754	5	Nipple		
57	969011	5	Gasket		
58	973924	2	Flange screw		
59	976944	2	Washer		(966674)
60	866699	1	Shut-off valve		
61		1	· Valve		
62		1	· Nut		
63	3825238	1	· Gasket kit		
64	3825240	1	· Magnet		
65	866927	1	Cable kit		
66	866664	1	· Connector unit		
67	844576	1	· Cable union		
68	845999	1	Bracket, oil return pipe, turbo		
69	3825603	1	Fuel hose		
70	74033	1	Hollow screw		
71	3825154	1	Overflow valve		For engine with electric fuel stop valve.
	35096	1	Overflow valve		For engine without electric fuel stop valve.
72	16496	1	Hollow screw		
73	947620	2	Gasket		
74	977677	1	Nipple		
75	957055	1	Nipple		
76	3825770	2	Fuel pipe		
77	956983	6	· Nut		
78	956969	6	· Ferrule		
79	865737	2	Fuel hose		
80	404279	4	Clamp		
81	950047	2	Screw		
82	955825	2	Nut		
83	965545	1	Bracket		
84	404279	1	Clamp		
85	950048	1	Screw		
86	955825	1	Nut		
87	955893	1	Washer		
88	865760	1	Pipe		
89	866933	1	Pipe		
90	865737	2	Fuel hose		
91	468480	1	Fuel pipe		
92	468481	1	Fuel pipe		
93	952631	1	Clamp		
94	956094	1	Screw		
95	955781	1	Nut		