

TD121G-87

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	862182	1	Injection pump	1751	REPL BY 3826534
	3826534	1	Injection pump		
	3803743	1	Injection pump, exch	3771	Exchange unit
2	478647	1	Bracket		
3		2	· Guide sleeve		
4	417588	1	· Guide sleeve		
5	955566	4	Screw		
6	940280	4	Spring washer		
7	940156	4	Screw		
8	190509	4	Washer		
9	477173	1	Pressure equalizer		
10	969011	1	Gasket		
11	8194541	1	Filter housing		(1676832)
12	471177	1	· Screw, air venting		
13	947620	1	· Gasket		
14	476438	1	Bracket		
15	3825133	2	Fuel filter		(466987)
16	6638088	2	· Gasket		
17	968062	3	Plug		
18	940162	1	Screw		L=38mm
	955536	1	Screw		L=45mm
19	960142	2	Washer		
20	942336	2	Spring washer		
21	955827	2	Nut		
22	940114	2	Screw		
23	942336	2	Spring washer		
24	468480	1	Fuel pipe		
25	468481	1	Fuel pipe		
26	25167	4	Hollow screw		
27	969011	8	Gasket		
28	404279	2	Clamp		
29	950047	1	Screw		
30	955825	1	Nut		
31	470514	1	Pressure oil line		
32	48634	1	Hollow screw		
33	947281	2	Gasket		
34	942081	1	Hollow screw		
35	11994	1	Gasket		
36	18666	1	Gasket		
37	865760	1	Pipe		(845937)
38	25167	1	Hollow screw		
39	969011	2	Gasket		
40	422246	1	Pipe		
41	25167	1	Hollow screw		
42	969011	2	Gasket		
43	11998	1	Gasket		
44	942007	1	Hollow screw		
45	942703	1	Gasket		
46	866933	1	Pipe		(845938)
47	965545	1	Bracket		
48	404279	1	Clamp		
49	950048	1	Screw		
50	955893	1	Washer		
51	955825	1	Nut		
52	404279	2	Clamp		
53	950047	1	Screw		
54	955825	1	Nut		
55		1	Leak-off line	1732	
56	35096	1	Overflow valve		
57	15304	1	Gasket		
58	969011	2	Gasket		

