



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	ALTERNATOR AND INSTALLATION COMPONENTS	030-0550	
2	466772	1	Starter motor		24V, REPL BY 465604
				030-1201	
	465604	1	Starter motor		24V
	3803068	1	Starter motor, exch		Exchange unit
		X	· COMPONENTS NOT SPEC.		
	843510	1	Starter motor		TD60B SPEC.867647, 867648, 867649, 867477.. REPLACED BY 1EA 847307 STARTER.. TD60B, BASE ENGINE 497890 MOXXXXX/50263-XXXXX/59194.
				030-1250	
	847307	1	Starter motor		24V. TD60B, BASE ENGINE 497890 MOXXXXX/59195-.
				030-1260	
	4774617	1	Starter motor		OIL PROTECTED STARTER.
				030-1250	
3	953486	3	Stud		
	953486	2	Stud		TO FLYWHEEL COVER FOR ALLISON CONVERTER MT643.
	955537	1	Screw		TO FLYWHEEL COVER FOR ALLISON CONVERTER MT643.
4	955827	3	Nut		
5	942336	3	Spring washer		
6	837791	2	Clutch housing		EARLY TYPE. REPLACED BY 2EA 845838, 1EA 955129.
	845838	2	Electrical distribut		LATE TYPE
6A	955129	1	Screw		
7	843538	1	Attaching plate		SIDE MOUNTING.
	844135	1	Hub		SPEC. 867446, 867477, 867618, 867649.. REAR MOUNTING.
8	837829	1	Terminal block		
9	88578	1	Fuse box		
	88578	2	Fuse box		SPEC. 867446, 867477, 867618, 867649.
10	942785	1	Fuse		16A
	943905	1	Fuse		25A
10	943905	2	Fuse		25A. ÅKERMAN SPEC. 867477.
11	941269	2	Cable grommet		
12	842390	1	Bridge connector		
	842390	2	Bridge connector		SPEC. 867446, 867477, 867618, 867649.
13	955546	1	Screw		
	955546	3	Screw		SPEC. 867446, 867477, 867618, 867649.
	955546	4	Screw		SPEC.867630,867649
14	941909	1	Spring washer		
	941909	3	Spring washer		SPEC. 867446, 867477, 867618, 867649.
	941909	4	Spring washer		SPEC.867630,867649
15	955826	1	Nut		
	955826	3	Nut		SPEC. 867446, 867477, 867618, 867649.
16	950059	3	Screw		
17	955894	3	Washer		
18	950021	2	Screw		SPEC. 867446, 867477, 867618, 867649.
19	941905	2	Spring washer		SPEC. 867446, 867477, 867618, 867649.
20	940092	2	Nut		SPEC. 867446, 867477, 867618, 867649.
21		1	CABLE HOLDER		
22		1	CABLE UNIT		
		1	CABLE UNIT		SPEC. 867446, 867477, 867618, 867649.
23		X	· CABLES AND TERMINALS	030-1550	
24	354671	1	Tachometer sensor		SEE GROUP 2A (837783)
25	925059	1	O-ring		
26	844085	1	Pressure sensor		
27	942490	1	T-nipple		
28	6639331	1	Pressure monitor		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
28A		1	CABLE UNIT		
		X	· CABLES AND TERMINALS	030-1550	
29	824552	1	Temperature sensor		SEE GROUP 2B
29A	844080	1	Temperature sensor		SEE GROUP 2B. TD60A SPEC.867446, TD60B SPEC.867477, 867618, 867648.. TD60D SPEC 867752, 867786.
30	11996	1	Gasket		
31	850420	1	Horn		
31A		1	CABLE UNIT		
		X	· CABLES AND TERMINALS	030-1550	
32	955827	1	Nut		
33	940114	1	Screw		
34	942336	1	Spring washer		
35	1504951	1	Relay		24V
	1504951	2	Relay		24V LATE TYPE. ÅKERMAN SPEC. 867477.
36	844850	1			ALT
				030-1500	
	844857	1	Instrument panel		ALT
				030-1500	
	844860	1	Instrument panel		ALT
				030-1500	
		1	SPEC.867618	030-1425	TD60B PP
37	352390	1	Level indicator		
38	11994	1	Gasket		
39	1501203	1	Level relay		
40	823666	1	Tachometer		
41	844957	1	Hour counter		24V
42	953261	1	Stud		GROUND CABLE-STARTER.
43	955827	2	Nut		GROUND CABLE-STARTER.
44	827149	1	Thermometer		ÅKERMAN SPEC. 867446.
45	241315	1	Starter switch		
46	948210	X	Strip clamp	030-1550	
47		1	CABLE HOLDER		
48		1	CABLE UNIT		
	845919	1	Cable trunk		SPEC.867618. ENGINE-LEFT SIDE.
	845921	1	Cable trunk		SPEC.867618. ENGINE-NIGHT SIDE.
		X	· CABLES AND TERMINALS	030-1550	
49	823416	1	Pressure monitor		SPEC.867648
50	823417	1	Hollow screw		SPEC.867648
51	957178	2	Gasket		SPEC.867648
52		1	STARTING ELEMENT AND INSTALLATION COMPONENTS	030-1300	