



REF	PART NO.	QTY	DESCRIPTION	NOTES
1	4774617	1	Starter motor	24V. OIL PROTECTED STARTER.
2		1	· HOUSING	
3		4	· POLE TERMINAL	
4	844413	1	· Field winding	
5	956350	8	· Screw	
6	844414	1	· Rotor	
7	243091	1	· · Needle bearing	
8	244315	1	· Bearing shield	
9	240481	1	· · Bearing bushing	
10	240478	4	· · Brush spring	
11	240479	1	· · Terminal screw	
12A	955322	1	· · Screw	
13		1	· · INSUL PLATE	
14	241149	1	· · Connector kit	
15	6643672	1	· · Connector kit	
16	243089	1	· Carbon brush set	
17		1	· BEARING	
18	243172	1	· · Gasket	
20	240453	1	· · Roller bearing	
21	240455	1	· · Bearing bushing	
22	240456	1	· Bearing housing	
23	244539	1	· Disc clutch	
34	6643675	1	· Starter pinion	
35	240473	1	· Key	
36	955246	4	· Screw	
37	941905	4	· Spring washer	
38	240457	1	· Spacer washer	
39	6643681	1	· Nut	
40	6643682	1	· Nut	
41	6643680	1	· Shaft	
42	844410	1	· · Washer	
43	6212617	1	· · Spring	
44	6212622	1	· · Ring	
45	844412	11	· · Ball	
46	240471	1	· · Lock ring	

REF	PART NO.	QTY	DESCRIPTION	NOTES
47	241904	X	· Adjusting washer	TH = 0.2 MM
	240486	X	· Adjusting washer	TH = 0.3 MM
	240487	X	· Adjusting washer	TH = 0.4 MM
48	6643677	1	· Stud	
49	6643678	3	· Stud	
50	955892	4	· Washer	
51	955781	4	· Nut	
52	240488	1	· Actuator solenoid	
53	955294	2	· Screw	
54	941907	2	· Spring washer	
55	244218	6	· Screw	
56	941905	6	· Spring washer	
57	940090	3	· Washer	
58	844415	1	· Relay	
59	243713	2	· Bolt	
60	240498	2	· Washer	
61	72225	1	· Gasket	
62	240496	1	· Protecting casing	
63	72202	2	· Gasket	
64	72201	2	· Washer	
65	941906	2	· Spring washer	
66	956094	2	· Screw	
67	6643679	2	· Screw	
68	941905	2	· Spring washer	