

DESCRIPTION	SEE SEC.	NOTES
ENGINE AND INSTALLATION COMPONENTS: TD60A	02A-0150	TD60A,TD60B
ENGINE AND INSTALLATION COMPONENTS: TD60B	02A-0150B	TD60A,TD60B
CYLINDER BLOCK AND RELATED PARTS: TD60A	02A-0350	TD60A,TD60B
CYLINDER BLOCK AND RELATED PARTS: TD60B	02A-0350B	TD60A,TD60B
FLYWHEEL HOUSING	02A-0500	TD60A,TD60B
FLYWHEEL AND FLYWHEEL HOUSING FOR ALLISON CONVERTER MT643	02A-0575	TD60B
CYLINDER HEAD: TD60A	02A-0700	TD60A,TD60B
CYLINDER HEAD: TD60B	02A-0700B	TD60A,TD60B
TIMING GEAR COVER AND GEARS	02A-0900	TD60A,TD60B
CAMSHAFT: TD60A	02A-1100	TD60A,TD60B
CAMSHAFT: TD60B	02A-1100B	TD60A,TD60B
CRANKSHAFT AND RELATED PARTS: TD60A	02A-1300	TD60A,TD60B
CRANKSHAFT AND RELATED PARTS: TD60B	02A-1300B	TD60A,TD60B
LUBRICATING SYSTEM, STANDARD MODEL: TD60A	02A-1500	TD60A,TD60B
LUBRICATING SYSTEM, STANDARD MODEL: TD60B	02A-1500B	TD60A,TD60B
LUBRICATING SYSTEM, ANGLE OF INCLANATION 10%Z9: TD60B	02A-1550	TD60B
LUBRICATING SYSTEM, ANGLE OF INCLANATION 40%Z9: TD60B	02A-1600	TD60B
OIL PUMP: 466387	02A-2100	
OIL PUMP: 4774185	02A-2125	
OIL SUMP PUMP AND INSTALLATION COMPONENTS: TD60B	02A-2275	TD60B
ELECTRICAL OIL SUMP PUMP AND INSTALLATION COMPONENTS: TD60A	02A-2300	TD60A,TD60B
ELECTRICAL OIL SUMP PUMP AND INSTALLATION COMPONENTS: TD60B	02A-2300B	TD60A,TD60B
ENGINE SUSPENSION: TD60A	02A-2600	TD60A,TD60B
ENGINE SUSPENSION: TD60B	02A-2600B	TD60A,TD60B
FLEXIBEL ENGINE SUSPENSION	02A-2650	TD60A,TD60B
ENGINE SUSPENSION, POWER PACK: TD60B	02A-2675	TD60B
AIR COMPRESSOR AND INSTALLATION COMPONENTS: TD60A	02A-2800	TD60A,TD60B
AIR COMPRESSOR AND INSTALLATION COMPONENTS: TD60B	02A-2800B	TD60A,TD60B
AIR COMPRESSOR: 351453	02A-2950	