



REF	PART NO.	QTY	DESCRIPTION	NOTES
1	844345	1	Centrifugal governor	
2	244243	1	· Regulator housing	
3	244095	1	· · Bushing	
4	244100	1	· Lever	
5	244192	1	· Washer	
6	244108	2	· Spacer washer	
7	244102	2	· O-ring	
8	843182	3	· Lock washer	
9	244105	1	· Tensioning ring	
10	844346	X	· Adjusting washer	TH = 0.2 MM
	244111	X	· Adjusting washer	TH = 0.3 MM
	844347	X	· Adjusting washer	TH = 0.4 MM
	244101	X	· Washer	TH = 0.5 MM
11	244113	1	· Spacer washer	
12	844354	1	· Companion flange	
13	244163	1	· Guide plate	
14	244125	1	· Lever	
15	244126	1	· Screw	
16	955892	1	· Washer	
17	941906	1	· Spring washer	
18	244127	1	· Nut	
19	244130	1	· Stop, shoulder	
20	244128	1	· Bushing	
21	244129	1	· Nut	
22	240769	1	· Spring washer	
23	244127	1	· Nut	
24	244096	1	· Lever	
25	244098	1	· Lever	
26	844352	2	· Plug	
27	244097	1	· Adjuster screw	
28	240056	1		
29	244123	1	· Bearing bolt	
30	244115	1	· Lever	
31	244122	1	· Adjusting washer	
32	240919	1	· Plug	
33	244121	1	· Leaf spring	
34	244117	2	· Adjuster screw	
35	955781	2	· Nut	(244116)
36	244119	1	· Screw	
37	244120	1	· Nut	
38	244106	1	· Brace	
39	244107	2	· Screw	
40	244150	1	· Control sleeve	
41	244151	1	· Needle bearing	
42	244256	X	· Adjusting washer	TH = 3.45 MM
	244257	X	· Adjusting washer	TH = 3.65 MM
	244258	X	· Adjusting washer	TH = 3.85 MM
	244259	X	· Adjusting washer	TH = 4.05 MM
	244260	X	· Adjusting washer	TH = 4.25 MM
	244152	X	· Adjusting washer	TH = 4.45 MM
	244153	X	· Adjusting washer	TH = 4.65 MM
	244154	X	· Adjusting washer	TH = 4.85 MM
	244155	X	· Adjusting washer	TH = 5.05 MM
43	244143	1	· Retainer	
44	244139	1	· Companion flange	
45	244140	4	· Rubber damper	
46	244141	1	· Washer	
47	870919	4	· Regulator weight	
48	244145	4	· Bearing bolt	
49	844348	X	· Adjusting washer	TH = 0.5 MM
	844349	X	· Adjusting washer	TH = 0.6 MM
	844350	X	· Adjusting washer	TH = 0.7 MM
	844351	X	· Adjusting washer	TH = 0.8 MM
50	843191	8	· Washer	

REF	PART NO.	QTY	DESCRIPTION	NOTES
51	244147	4	· Screw	
52	244146	4	· Clamping jaw	
53	244137	1	· Bearing washer	
54	244138	1	· Cardboard tube	
55	244142	1	· Nut	
56	244170	1	· Lever	
57	244169	1	· Bushing	
58	243786	1	· O-ring	
59	233816	1	· Washer	
60	951670	1	· Retaining ring	
61	244197	1	· Spring	
62	244244	1	· Lever	
63	244174	1	· Screw	
64	842302	1	· Washer	
65	955780	1	· Nut	
66	244131	1	· Shaft	
67	844357	1	· Spring	
68	244133	1	· Plug	
69	244135	1	· Cover	
70	244134	1	· Gasket	
71	956091	10	· Screw	
72	941906	10	· Spring washer	
73	244166	1	· Cover	
74	244165	1	· Gasket	
75	244167	1	· Adjuster screw	
76	844355	1	· Bolt	
77	244110	1	· Nut	
78	844356	1	· Nut	
79	244162	1	· Gasket	
80	955272	8	· Screw	
81	941906	8	· Spring washer	
82	844353	1	· Pin	
83	843192	1	· Nut	
84	244196	1	· Stop, shoulder	
85	244171	1	· Lock washer	