



8322

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	4881097	1	Starter motor	24V
1A	6212612	1	· Field winding	
2	956350	8	· Screw	
3	6212797	1	· Bearing housing	
4	240455	1	· · Bearing bushing	
5	240453	1	· · · Roller bearing	
6	243172	1	· · Gasket	
7	6212614	1	· Rotor	
8	243091	1	· · Needle bearing	
9	240456	1	· Bearing housing	
10	955246	4	· Screw	
11	941905	4	· Spring washer	
12	240457	1	· Spacer washer	
13	244539	1	· Disc clutch	
14	6643680	1	· Shaft	
15	844410	1	· · Washer	
16	6212617	1	· · Spring	
17	6212622	1	· · Ring	
18	184453	11	· · Ball	
19	240471	1	· · Lock ring	
20	6643675	1	· Starter pinion	
21	240473	1	· Key	
22	1696396	1	· Nut	
23	940090	3	· Washer	
24	244315	1	· Bearing shield	
25	240478	4	· · Brush spring	
26	240479	1	· · Terminal screw	
27	955322	1	· · Screw	
28		1	· · INSULATING PLATE	
29	240481	1	· · Bearing bushing	
30	6643672	1	· · Connector kit	
31	241149	2	· · Connector kit	
32	6212621	1	· Carbon brush set	
33	6643679	2	· Screw	
34	244218	6	· Screw	
35	941905	4	· Spring washer	
36	72225	1	· Gasket	
37	241904	X	· Adjusting washer	TH = 0,2 MM
	240486	X	· Adjusting washer	TH = 0,3 MM
	240487	X	· Adjusting washer	TH = 0,4 MM
38	6643677	1	· Stud	
39	6643678	3	· Stud	
40	955781	4	· Nut	
41	955792	4	· Nut	
42	6212620	1	· Cover	
43	243713	2	· Bolt	
44	6212619	2	· Washer	
45	72202	2	· Gasket	
46	72201	2	· Washer	
47	941906	2	· Spring washer	
48	956094	2	· Screw	
49	240493	1	· Starter solenoid	
50	240488	1	· Actuator solenoid	
51	955294	2	· Screw	
52	941907	2	· Spring washer	