



8126

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	466387	1	Oil pump		
				02A-2100	
2	62109	2	Lock washer		
3	955538	4	Screw		
4	844702	1	Suction pipe		
5	414621	1	Strainer		
6	118125	1	Lock ring		
7	948229	1	O-ring	IK	
8	955530	2	Screw		
9	941907	2	Spring washer		
10	465680	1	Tube		(844755)
11	949656	1	O-ring	IK	(191058)
12	955530	2	Screw		
13	941907	2	Spring washer		
14	466906	1	Fitting		
15	842133	1	Baffle plate		
16	955523	2	Screw		
17	940113	2	Screw		
18	941907	2	Spring washer		
	942385	2	Disc spring		
19	821343	1	Oil pan		
20	192538	1	Magnetic plug		
21	18677	1	Gasket	IK	02A-2300
22	420025	1	Gasket	IK	
23	942402	34	Flange screw		L = 16 MM
24	845181	1	Oil dipstick		(844626)
25	836179	1	Tube		
26	421123	1	Reducing valve		
27	949721	1	O-ring	IK	(925062)
28	940100	2	Screw		
29	941906	2	Spring washer		
30	4785974	1	Oil filter		(423135) SEE GROUP 2B
31	423067	1	Nipple		SEE GROUP 2B
32	949656	2	O-ring	IK	SEE GROUP 2B (191058)
33	466339	1	Oil filter housing		SEE GROUP 2B
34	952075	1	· Plug		SEE GROUP 2B
35	940115	3	Screw		SEE GROUP 2B
36	942336	3	Spring washer		SEE GROUP 2B
37	420365	1	Oil cooler		SEE GROUP 2B
38	469483	2	Sealing ring	IK	SEE GROUP 2B (422581)
39	944012	1	Screw		L = 19 MM. REPLACED BY 1EA 940135, 1EA 941907, 1EA 955894.
39A	940135	1	Screw		L = 22 MM
39B	941907	1	Spring washer		
39C	955894	1	Washer		
40	807183	1	Spacer sleeve	02A-2300	
41	955982	1	O-ring		
42		1	· EL.SUMP PUMP AND INSTALLATION COMPONENTS	02A-2300	