



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	4774185	1	Oil pump		
				02A-2125	
2	421404	1	Baffle		
3	955538	4	Screw		
4	844542	1	Delivery pipe		
5	947061	1	Gasket	IK	
6	955524	2	Screw		
7	941907	2	Spring washer		
8	844558	1	Suction pipe		
9	948229	1	O-ring		
10	955524	2	Screw		
11	941907	2	Spring washer		
12	403483	1	Wire gauze		
13	118123	1	Lock ring		
14	466906	1	Fitting		
15	844619	1	Drain pipe		
16	844637	1	O-ring	IK	
17	944446	2	Screw		
18	941907	2	Spring washer		
19	821343	1	Oil pan		
20	192538	1	Magnetic plug		
21	18677	1	Gasket	IK 02A-2300	
22	420025	2	Gasket	IK	
23	942402	34	Flange screw		L = 16 MM
24	844626	1	Oil dipstick		
25	836179	1	Tube		
26	421123	1	Reducing valve		
27	949721	1	O-ring	IK	(925062)
28	940100	2	Screw		
29	941906	2	Spring washer		
30	4785974	1	Oil filter		(423135) SEE GROUP 2B
31	423067	1	Nipple		SEE GROUP 2B
32	949656	2	O-ring	IK	SEE GROUP 2B (191058)
33	466339	1	Oil filter housing		SEE GROUP 2B
34	952075	1	· Plug		SEE GROUP 2B
35	940115	3	Screw		SEE GROUP 2B
36	942336	3	Spring washer		SEE GROUP 2B
37	420365	1	Oil cooler		SEE GROUP 2B
38	469483	2	Sealing ring	IK	SEE GROUP 2B (422581)
39	942624	1	Screw		
40	955982	1	O-ring	IK	
41	844565	1	Tube		
42	948229	1	O-ring	IK	
43	959795	2	Screw		
44	941907	2	Spring washer		
45	844533	1	Baffle plate		
46	942624	2	Screw		
47	956567	1	Screw		
48	944012	1	Screw		L = 19 MM. REPLACED BY 1EA 940135, 1EA 941907, 1EA 955894.
48A	940135	1	Screw		L = 22 MM
48B	941907	1	Spring washer		
48C	955894	1	Washer		
49	807183	1	Spacer sleeve	02A-2300	
50		1	· EL.SUMP PUMP AND INSTALLATION COMPONENTS	02A-2300	