



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	465257	1	Timing gear casing		
2	941511	1	Pin		
3	941510	1	Pin		
4	421057	1	Gasket	IK	
5	955525	5	Screw		
6	941571	5	Lock washer		
7	421080	1	Crankshaft gear	02A-1300	
8	422253	1	Woodruff key	02A-1300	
9	420172	1	Oil deflector	02A-1300	
10	467463	1	Bearing spindle		
11	4774662	1	Idler gear		
12	467529	1	Thrust washer		
13	467528	1	Bearing shield		
14	422316	3	Screw		
15	942180	3	Washer		
16	421079	1	Gear	02A-1120	
17	950588	1	Pin	02A-1120	
18	940128	3	Screw	02A-1120	
19	467052	1	Lock washer	02A-1120	
20	467055	3	Washer	02A-1120	
21	842467	1	Gear		SEE GROUP 2C
22	421046	1	Drive	02A-2100	
23	423087	1	Gear		
			Bulletin 45-01	45-01-EN	Timing Gears, 71, 100, 121
24	354671	1	Tachometer sensor		SEE GROUP 3
24A	943681	1	Plug		STD
25	925059	1	O-ring	IK	
26	465056	1	Gasket	IK	
27	4773577	1	Cover		
28	471055	1	· Sealing ring	IK	
29	942083	1	· Seal	IK	
30	955530	5	Screw		L = 83 MM
	955526	1	Screw		L = 51 MM
	940186	10	Screw		L = 38 MM
31	953254	2	Stud		
32	941907	18	Spring washer		
33	955826	2	Nut		
34	420185	1	Hatch		
35	423123	1	Sealing ring	IK	
36	940094	5	Screw		
37	941906	5	Spring washer		
38	465735	1	Cover		
	846724	1	Cover		FOR ALTERNATOR LOW RIGHT-AND TWIN INSTALLATION.
39	465058	1	Seal	IK	
40	955535	1	Screw		L = 32 MM
	955539	1	Screw		L = 64 MM
	956581	1	Screw		L = 16 MM. FOR ALTERNATOR LOW RIGHT-AND TWIN INSTALLATION.
	956588	1	Screw		L = 51 MM. FOR ALTERNATOR LOW RIGHT-AND TWIN INSTALLATION.
41	942336	2	Spring washer		
42	420178	1	Cover		
43	413619	1	Gasket		
44	953345	3	Stud		
45	955828	3	Nut		
46	941911	3	Spring washer		