



7643

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	844459	1	Injector	
2		1	· NOZZLE HOLDER	
3	240579	1	· · Hollow screw	
4	947620	2	· · Gasket	(233321)
5	844294	1	· · Gasket	
6	844295	1	· · O-ring	
7	244443	1	· · Fitting	
8	244797	X	· · Adjusting washer, SHIM	TH = 1,000 MM (844299)
	846960	X	· · Adjusting washer, SHIM	TH = 1,020 MM (844300)
	846945	X	· · Adjusting washer, SHIM	TH = 1,040 MM (844301)
	846961	X	· · Adjusting washer, SHIM	TH = 1,080 MM (844302)
	844303	X	· · Adjusting washer	TH = 1,100 MM
	244804	X	· · Adjusting washer	TH = 1,120 MM (6212418)
	846947	X	· · Adjusting washer, SHIM	TH = 1,140 MM (844342)
	846963	X	· · Adjusting washer, SHIM	TH = 1,180 MM (844343)
	244799	X	· · Adjusting washer	TH = 1,200 MM (844304)
	6212417	X	· · Adjusting washer	TH = 1,220 MM
	244805	X	· · Adjusting washer	TH = 1,240 MM
	244807	X	· · Adjusting washer, SHIM	TH = 1,280 MM (846964)
	844308	X	· · Adjusting washer	TH = 1,300 MM
	244789	X	· · Adjusting washer, SHIM	TH = 1,320 MM (846965)
	244908	X	· · Adjusting washer, SHIM	TH = 1,340 MM (846950)
	846966	X	· · Adjusting washer, SHIM	TH = 1,380 MM (844311)
	244800	X	· · Adjusting washer, SHIM	TH = 1,400 MM (844312)
	6212393	X	· · Adjusting washer, SHIM	TH = 1,420 MM (844313)
	244790	X	· · Adjusting washer, SHIM	TH = 1,440 MM (846952)
	244802	X	· · Adjusting washer, SHIM	TH = 1,480 MM (846967)
	844316	X	· · Adjusting washer	TH = 1,500 MM
	244791	X	· · Adjusting washer, SHIMS	TH = 1,520 MM (846968)
	846954	X	· · Adjusting washer	TH = 1,540 MM
	846969	X	· · Adjusting washer	TH = 1,580 MM
	244793	X	· · Adjusting washer	TH = 1,600 MM (844320)
	846970	X	· · Adjusting washer, SHIM	TH = 1,620 MM (844321)
	244806	X	· · Adjusting washer, SHIM	TH = 1,640 MM (846956)
	244803	X	· · Adjusting washer, SHIM	TH = 1,680 MM (846972)
	844324	X	· · Adjusting washer	TH = 1,700 MM
	244794	X	· · Adjusting washer, SHIMS	TH = 1,720 MM (844325)
	846957	X	· · Adjusting washer, SHIM	TH = 1,740 MM

REF	PART NO.	QTY	DESCRIPTION	NOTES
8				(844326)
	846975	X	• • Adjusting washer	TH = 1,780 MM
	844328	X	• • Adjusting washer	TH = 1,800 MM
	6212420	X	• • Adjusting washer, SHIM	TH = 1,820 MM
				(844329)
	846958	X	• • Adjusting washer, SHIM	TH = 1,840 MM
				(844330)
	244812	X	• • Adjusting washer, SHIM	TH = 1,880 MM
				(846977)
	844332	X	• • Adjusting washer	TH = 1,900 MM
	244795	X	• • Adjusting washer, SHIM	TH = 1,920 MM
				(846978)
	846959	X	• • Adjusting washer, SHIM	TH = 1,940 MM
				(844334)
	846980	X	• • Adjusting washer, SHIM	TH = 1,980 MM
				(844335)
9	244444	1	• • Spring	
	244820	1	• • Compression spring	
10	244445	1	• • Push rod	REPLACED BY 1EA 244820, 1EA 244821.
	244821	1	• • Pressure bolt	
11	244537	1	• • Washer	
12	844339	2	• • Locating pin	
13	244447	2	• • Pin	
14	244448	1	• • Cap nut	
15	844460	1	• Nozzle	