



8322

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	4881097	1	Starter motor	
1A		1	· Field winding	
2		8	· Screw	
3		1	· Bearing housing	
4	240455	1	· · Bearing bushing	
5	240453	1	· · Roller bearing	
6	243172	1	· · Gasket	
7		1	· Rotor	
8	243091	1	· · Needle bearing	
9	240456	1	· Bearing housing	
10	969407	4	· Screw	
11	941905	4	· Spring washer	
12	240457	1	· Spacer washer	
13	244539	1	· Disc clutch	
14	6643680	1	· Shaft	
15		1	· · Washer	
16	6212617	1	· · Spring	
17	6212622	1	· · Ring	
18	184453	11	· · Ball	
19	240471	1	· · Lock ring	
20	11994396	1	· Start gear	(6643675)
21	240473	1	· Key	
22	1696396	1	· Nut	
23	940090	3	· Washer	
24		1	· Bearing shield	
25	240478	4	· · Brush spring	
26		1	· · Terminal screw	
27	965186	1	· · Flange screw	
28		1	· · Isolation plate	
29	240481	1	· · Bearing bushing	
30	6643672	1	· · Connector kit	
31	241149	2	· · Connector kit	
32	3094854	1	· Carbon brush set	(6212621)
33	6643679	2	· Screw	
34		6	· Screw	
35	941905	4	· Spring washer	
36	72225	1	· Gasket	
37	241904	X	· Shim	TH=0,20mm
		X	· Shim	TH = 0,30mm
	240487	X	· Shim	TH=0,40mm
38	6643677	1	· Stud	
39		3	· Stud	
40	955781	4	· Nut	
41	955792	4	· Nut	
42		1	· Cover	
43		2	· Bolt	
44		2	· Washer	
45	72202	2	· Gasket	
46	72201	2	· Washer	
47	941906	2	· Spring washer	
48	956094	2	· Screw	
49	240493	1	· Starter solenoid	
50	240488	1	· Actuator solenoid	
51	955294	2	· Screw	
52	941907	2	· Spring washer	