



REF	PART NO.	QTY	DESCRIPTION	NOTES
1	1590264	1	Compressor	REPL BY 1612335
2		1	· CYLINDER BLOCK WITH CRANKCASE	
3	1518347	2	· · Valve seat	
4	1518348	2	· · Bushing	
5		1	· COVER	
6	1518350	1	· · Bushing	
7		6	· SCREW	
8		6	· SPRING WASHER	
9	1518351	1	· Cover	
10	1697703	1	· Gasket	IK
11		10	· SCREW	
12		10	· SPRING WASHER	
13	1518353	1	· Crankshaft	
14	11014	1	· Ball bearing	
15	346520	1	· Lock ring	
16	1518354	1	· Spacer ring	
17	1518355	1	· Nut	
18	1517545	1	· Key	
19	3090257	2	· Connecting rod	(1518356)
20	1518357	4	· · Screw	
21	328738	4	· · Lock washer	
22	1697706	2	· Piston	STD D
22	1518359	2	· Piston	OVER SIZE 0,010
22	1518360	2	· Piston	OVER SIZE 0,020
23	1518361	2	· · Piston ring	STD D, REPL BY 272896
	1518362	2	· · Piston ring	OVER SIZE 0,010
	1518363	2	· · Piston ring	OVER SIZE 0,020
24	1518364	2	· · Piston ring	STD D, REPL BY 272896
	1518365	2	· · Piston ring	OVER SIZE 0,010
	1518366	2	· · Piston ring	OVER SIZE 0,020
25	1518367	2	· · Piston ring	STD D, REPL BY 272896
	1518368	2	· · Piston ring	OVER SIZE 0,010
	1518369	2	· · Piston ring	OVER SIZE 0,020
27		2	· · WRIST PIN	
28	1518371	4	· · Lock ring	
29	1518372	1	· Plate	
30	1697704	1	· Gasket	IK
31	1518374	1	· Cylinder head	
32	1697705	1	· Gasket	IK
33	1518376	11	· Screw	
	1518377	2	· Screw	
34		13	· SPRING WASHER	
35	1518378	1	· Lock pin	
36		2	· VALVE SPRING	IK
37		2	· VALVE PLATE	IK
38		2	· PISTON	IK
39		2	· O-RING	IK
40		1	· SPRING	IK
41	1518379	1	· Pressure plate	
42		2	· VALVE SPRING	IK
43		2	· VALVE	IK
44		2	· GUIDE	IK

REF	PART NO.	QTY	DESCRIPTION	NOTES
45	191026	1	· Plug	
	3090471	1	Repair kit	(270698)