



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	847186	1	Water pump		
	3803210	1	Circ. pump, exch		Exchange unit
2		1	· HOUSING		
3	846918	1	· Shaft		
4	421306	1	· Wear ring		
5	1545283	1	· Sealing ring		
6	70913	1	· Deflector		
7	181670	1	· Ball bearing		
8	846917	1	· Pulley		2-GROOVE
9	181538	1	· Ball bearing		
10	417638	1	· Spacer sleeve		
11	11013	1	· Ball bearing		
12	914462	1	· Lock ring		
13	466286	1	· Hub		
14	422493	1	· Hub		
15	940132	4	· Screw		
16	941907	4	· Spring washer		
17	952077	1	· Plug		
18	421215	1	Gasket	IK	
19	420162	1	Seal	IK	
20	466202	1	Thermostat housing		(420153)
21	968145	1	Plug		(952076)
22	952077	2	Plug		
23	875787	2	Thermostat kit		76%Z9
	875788	2	Thermostat kit		70%Z9 ALT
24	416033	2	Sealing ring	IK	
25	420155	1	Tube		
26	940162	3	Screw		
27	942336	3	Spring washer		
28	843586	1	Nipple		
29	824552	1	Temperature sensor		
29A	180761	1	Plug		
29B	11996	1	Gasket		
30	955539	2	Screw		
31	942336	2	Spring washer		
32	952077	1	Plug		
33	968145	1	Plug		(952076)
33A	16291	1	Nipple		
36		1	PULLEY		SEE GROUP 2A
37	966395	2	V-belt set		L = 2X1225 MM
38		1	AUTOMATIC BELT TENSIONER AND INSTALLATION COMPONENTS	02B-0500	
39	845143	1	Riser		
40	925069	1	O-ring		
41	940135	2	Screw		
42	941907	2	Spring washer		
43	846465	1	Coolant pipe		
44	821128	1	Hose		
45	943480	2	Clamp		
46	943480	1	Clamp		
47	952077	1	Plug		
48	955531	1	Screw		
49	941907	1	Spring washer		
50	821542	1	Spacer sleeve		
51	421159	1	Flange		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
52	421161	1	Cover		
53	952077	1	Plug		
54	420160	3	Gasket	IK	
55	421160	1	Gasket	IK	
56	955535	2	Screw		
57	955540	2	Screw		
58	955537	2	Screw		
59	942336	6	Spring washer		
60	940161	5	Screw		L = 45 MM
	955526	1	Screw		L = 51 MM
61	941907	6	Spring washer		
62		1	CABLE HOLDER		
63	955512	1	Screw		
64	941906	1	Spring washer		