



6344

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	827349	1	Alternator		28V 25A
				030-0951	
2		1	CHARGING RELAY AND INSTALLATION COMPONENTS	030-0350	
3	955699	1	Screw		
	941909	1	Spring washer		
4	823107	1	Tensioner		
5	940186	1	Screw		
6	191172	1	Washer		
7	950353	1	Lock nut		
8	947951	1	V-belt		
9	843248	1	Pulley		
10	827150	1	Temperature sensor		
11	11996	1	Gasket	IK	
12	881432	1	Pressure sensor		
13	870998	1	Starter motor		24V REPL BY 847308
				030-1051	
	847308	1	Starter motor COMPONENTS NOT SPEC.		24V
14	953486	3	Stud		
15	955827	3	Nut		
16	942336	3	Spring washer		
17	822858	1	Thermo monitor		93%Z9C
18	843812	1	Switch		(881348)
19	942490	1	T-nipple		
20	850420	1	Horn		
21	955827	1	Nut		
22	955535	1	Screw		
23	942336	1	Spring washer		
24	820553	1			MECHANICAL
	820554	1	Hour counter		MECHANICAL
	820555	1	Hour counter		MECHANICAL
	820556	1	Hour counter		MECHANICAL
25	325842	1	Nut		
26	354671	1	Tachometer sensor		
27		1	INSTRUMENT PANEL AND INSTALLATION COMPONENTS	030-1300	
		1	INSTRUMENT PANEL AND INSTALLATION COMPONENTS	030-1350	
28		1	CONNECTING BOX AND FUSE BOX	030-0450	
29		1	STOP SOLENOID AND INSTALLATION COMPONENTS		SEE GROUP 2D
30	836197	1	Cable trunk CABLES AND TERMINALS	030-1500	
31	948210	X	Strip clamp		(827353)
32	942400	1	Clamp		
33	823416	1	Pressure monitor		
34	823417	1	Hollow screw		
35	957178	2	Gasket	IK	
36	352390	1	Level indicator		
37	11994	1	Gasket		
38	1501203	1	Level relay		
39	11411	1	Ground cable		
40	870451	1	Relay		
41	950019	2	Screw		
42	941905	2	Spring washer		
43		1	STARTING ELEMENT AND INSTALLATION COMPONENTS	030-1275	
44		1	BATTERY BOX AND INSTALLATION COMPONENTS	030-1475	